



# ***Workshop Manual***

# ***F4 serie oro***



**Engine**


Part Number: 8A0092871



# ENGINE OVERHAUL



<b>ENGINE DISASSEMBLY, OVERHAUL AND ASSEMBLY .....</b>	<b>VII.2</b>	Start .....	VII.56
<b>PARTS CLEANING .....</b>	<b>VII.6</b>	Start free wheel .....	VII.57
<b>COUPLING .....</b>	<b>VII.6</b>	Neutral switch .....	VII.57
<b>GENERAL RULES FOR PARTS ASSEMBLY .....</b>	<b>VII.6</b>	<b>CRANKCASE AND CRANKSHAFT .....</b>	<b>VII.58</b>
<b>CYLINDER COMPRESSION MEASUREMENT .....</b>	<b>VII.7</b>	Oil sump .....	VII.59
<b>CO ADJUSMENT .....</b>	<b>VII.8</b>	Crankshaft removal .....	VII.60
<b>HEAD .....</b>	<b>VII.10</b>	Crankshaft overhaul .....	VII.61
Head assy removal .....	VII.11	Crankshaft installation .....	VII.62
Timing system parts .....	VII.14	Rod disassembly .....	VII.65
Head assy inspection .....	VII.17	Bearings removal .....	VII.65
Head assy assembly .....	VII.18	Crank pin - bearings coupling .....	VII.65
<b>HEAD PARTS DISASSEMBLY .....</b>	<b>VII.22</b>	Bearing installation .....	VII.65
Valve removal .....	VII.22	Timing chain inspection and installation .....	VII.66
Valve seat maintenance .....	VII.24		
External diameter of the valve seat sealing surface .....	VII.24		
Valve seat replacement .....	VII.25		
Valve guide control and maintenance .....	VII.25		
Valve guide removal .....	VII.26		
Valve guide installation .....	VII.26		
Valve .....	VII.26		
Valve - Valve guide coupling .....	VII.26		
Springs .....	VII.26		
Valve assembly .....	VII.27		
Valve clearance adjustment .....	VII.28		
Cam chain tensioner .....	VII.29		
<b>CYLINDER AND PISTON GROUP .....</b>	<b>VII.30</b>		
Cylinder and piston removal .....	VII.31		
Cylinder overhauling .....	VII.31		
Piston overhauling .....	VII.31		
Cylinder - piston coupling .....	VII.32		
Piston pin overhauling .....	VII.32		
Piston pin - piston coupling .....	VII.32		
Piston pin - rod small end coupling .....	VII.32		
Rings .....	VII.33		
Rings - cylinder coupling .....	VII.33		
Cylinder and piston installation .....	VII.33		
<b>CLUTCH .....</b>	<b>VII.34</b>		
Clutch removal .....	VII.35		
Clutch overhauling .....	VII.38		
Clutch installation .....	VII.39		
<b>GEAR AND GEAR CONTROL .....</b>	<b>VII.40</b>		
Gear group removal .....	VII.41		
Gear control .....	VII.41		
Shift drum .....	VII.42		
Drive and output shafts .....	VII.43		
Gear group overhaul .....	VII.44		
Shift forks .....	VII.44		
Installation .....	VII.45		
<b>CRANKCASE ACCESSORIES .....</b>	<b>VII.48</b>		
Alternator .....	VII.49		
Starting motor .....	VII.49		
Oil pump .....	VII.50		
Water pump .....	VII.52		
Water pump removal .....	VII.53		
Water pump parts disassembly .....	VII.53		
Water pump parts overhauling .....	VII.54		
Water pump parts assembly .....	VII.54		



## ENGINE OVERHAUL

### Engine disassembly, overhaul and assembly



#### **WARNING**

During this operations, flammable vapours can occur and metallic parts can be ejected at high speed

For this reason you have to:

- Operate far from flames and sparks
- Wear protective clothes and glasses



#### **ATTENTION**

If a cylinder part replacement for wear is needed, we strongly recommend to verify and replace if necessary the same part in the whole cylinders group.

The contemporary substitution of these parts is recommended:

- Pistons with their rings and pins
- Valves with their springs, cotters, plates and shim adjustment
- Valve guides with their valves, springs, cotters, plates and shim adjustment
- Main bearings
- Every part subjected to uniform wear independently from the position number of its cylinder



#### **ATTENTION**

To let the engine work at his best, every coupling must be in the clearance limits

A tight coupling may cause seizures when moving parts heat

A slack coupling causes vibrations with faster wear of the moving parts.



#### **NOTE**


Every legend (right, left, upper, lower, front rear) is referred to the running direction of the motorcycle




#### **NOTE**

The numeration of cylinders, of the main bearings and of their parts is increasing from left to right referred to the running direction of the motorcycle

# ENGINE OVERHAUL




ITEM	STANDARD	WEAR LIMIT
CYLINDER COMPRESSION  Minimum loadless voltage of the battery	min.: 7.5    max.: 13.5 bar at 280 rpm  12,5 Volt	
CO ADJUSTMENT  Throttle angle CO value	1.5° ~ 1.7° 4.5% ± 0.5% at 1100 ± 50 rpm	
VALVES Sealing external diameter Exhaust.....  Inlet.....  Sealing face thickness.....  Stem-guide clearance Exhaust..... Inlet.....  Guide internal diameter.....  Valve stem Exhaust..... Inlet.....  Valve spring Exhaust..... Inlet.....  Valve-cam clearance Exhaust..... Inlet.....	24.6 <sup>+0.3</sup> <sub>0</sub> mm  28.6 <sup>+0.3</sup> <sub>0</sub> mm  1 <sup>0</sup> <sub>-0.3</sub> mm  0.02 ÷ 0.04 mm..... 0.01 ÷ 0.03 mm.....  4.5 <sup>+0</sup> <sub>+0.012</sub> mm.....  4.475 ± 0.005 mm..... 4.485 ± 0.005 mm.....  30.5 mm..... 32.6 mm.....  0.20 ÷ 0.25 0.15 ÷ 0.20	Coupling: 0.10 mm  0.08 mm  4.55 mm  4.455 mm 4.465 mm  30 mm 32.1 mm




## ENGINE OVERHAUL

ITEM	STANDARD	WEAR LIMIT
<b>CYLINDERS - PISTONS</b>		
Piston ovalization.....	.....	0.015 mm
Piston - cylinder clearance.....	0.025 ÷ 0.045 mm	0.10 mm
Piston - piston pin clearance.....	0.004 ÷ 0.012 mm	0.03 mm
Piston pin-rod small end clearance..	0.015 ÷ 0.032 mm	0.04 mm
Rings thickness		
1°.....	0.8 <sup>-0.01</sup> <sub>-0.03</sub> mm.....	0.75 mm
2°.....	1 <sup>-0.01</sup> <sub>-0.025</sub> mm.....	0.96 mm
Scraper ring.....	2 <sup>0</sup> <sub>-0.1</sub> mm.....	1.88 mm
Rings-cylinder maximum clearance		
1°.....	0.2 ÷ 0.4 mm.....	0.6 mm
2°.....	0.2 ÷ 0.4 mm.....	0.6 mm
Scraper ring.....	0.2 ÷ 0.7 mm.....	1 mm
<b>CLUTCH</b>		
Plates thickness.....	3 mm.....	2.8 mm
Springs.....	.....	38.8 mm

# ENGINE OVERHAUL



ITEM	STANDARD	WEAR LIMIT
GEAR		
Fork pin-groove clearance.....	0.35 ÷ 0.15 mm.....	0.65 mm
Drum slot width.....	7.05 ÷ 7.15 mm.....	7.35 mm
Fork pin diameter.....	6.8 ÷ 6.9 mm.....	6.7 mm
Idle gears minimum axial clearance.....	0.10 mm	
Fork-gear maximum clearance.....		0.7 mm
Gear limit		
Drive.....		5.6 mm
Output.....		4.6 mm
Gear selection forks limit		
Drive (5 <sup>a</sup> - 6 <sup>a</sup> ).....		4.65 mm
Output (1 <sup>a</sup> - 2 <sup>a</sup> , 3 <sup>a</sup> - 4 <sup>a</sup> ).....		3.65 mm
Slot-fork clearance.....	0.2 ÷ 0.3 mm	0.7
CRANKCASE - CRANKSHAFT		
Main bearings working clearance....	0.012 ÷ 0.038 mm.....	0.06 mm
Big end bearings working clearance.....	0.036 ÷ 0.061 mm.....	0.08 mm
Crankshaft axial clearance.....	0.2 mm	



## ENGINE OVERHAUL

---

### Parts cleaning

Always clean parts with biodegradable solvents and dry with compressed air  
Always clean the assy before disassembly and then the single parts.  
Clean everything before installation

### Coupling

To let the engine work at his best, every coupling must be in the clearance limits

A tight coupling may cause seizures when moving parts heat

A slack coupling causes vibrations with faster wear of the moving parts.

### General rules for parts installation

To reassembly the various parts you'll have to execute the procedures in opposite sense of the assembly, paying attention to the particular operations, if specified.

Always replace gaskets oil seals, metallic stoppers, washers in straining material and self-locking nuts.

Bearings wear is done for a certain number of working hours so we recommend their replacement, as the wear check is difficult.

These notes are an addition to the dimensional checks described in the various chapters.

Parts cleaning is basic; bearings and all the other wearing parts need lubrication with engine oil before installation.

Tighten screws and nuts to the prescribed torque setting.


In the next pages disassembly, overhaul and assembly operations of the various parts of the engine are described in sequence to get to the complete engine disassembly.

Remove the engine from the frame;

drain oil from the oil sump;

remove the spark plugs and close their seats with clean clothes, to avoid any little objects (washers, etc....) falling into the engine

## ENGINE OVERHAUL



### Cylinder compression measurement

To execute this operation you need the following special tool:

Spark plug tool: n° 89013

Compression gauge.

Compression gauge adapter.

- A) Warm the engine to the working temperature;
  - B) Turn off the engine, remove fairing, tank airbox and spark plugs;
  - C) Measure the cylinder compression
- Run the engine in the W.O.T. position with the starting motor since the compression gauge indicator doesn't rise anymore; the indicated compression value is at the maximum.



#### NOTE

**The battery must be completely charged.**

Cylinder compression

Range: **min.: 7.5**                      **max.: 13.5 bar**


**at 280 rpm**


- Repeat the same procedure for the other cylinders
- ⇒ If the compression value is higher than the maximum, check the following points
- A) Combustion chamber and piston crown coke
  - B) The head gasket thickness is not correct
  - C) The valve stem seal and or the piston rings are damaged
- ⇒ If the compression value is then the maximum, check the following points
- A) One or more valves seat are damaged and the valves don't withstand the pressure (leaking)
  - B) One or more valves have a zero working clearance
  - C) The piston - cylinder clearance is too wide
  - D) The cylinder head and or the head gasket are damaged
  - E) The piston ring - slot clearance is too wide.




#### NOTE

**Check the battery voltage before executing the compression check as the value is strongly influenced by the revolution speed of the engine, that is, from the battery voltage.**





## ENGINE OVERHAUL



### CO ADJUSTMENT




A) Verify and regulate if necessary the throttle idle opening with the Marelli DST software. The throttle angle must be  $1.5^\circ$ ; hunting between  $1.5^\circ$  and  $1.7^\circ$  is admitted; hunting between  $1.5^\circ$  and  $1.3^\circ$  is not admitted. Correct if necessary by acting on the screw (1) on the opening pulley of the throttle. Apply Loctite 242 after the adjustment.




### NOTE

**Act on the right screw only (the smaller one).**


- B) Verify the correct working of the temperature and pressure sensors, the atmospheric pressure and the battery voltage
- C) Wait for the cooling fan start with engine idle
- D) Connect the vacuummeter to the connections (2) and the CO tester to the connection (3) unscrewing the cap with a 5 mm allen key.



## ENGINE OVERHAUL





- E) Regulate the cylinders vacuum by acting on the by-pass screw of the throttles holder (1), verifying the CO value (with the fan cooler working) is in a range of 4% and 5% ( $4.5 \pm 0.5\%$ ).  
The revolution speed of the engine must be  $1100 \pm 50$  rpm (with the fan cooler working).
- F) Disconnect the vacuum meter, speed up the engine and verify the throttle gets back to the value previously defined, wait for the CO value stabilisation and verify CO and rpm values are in the given clearance.
- G) If the values are out of range check the vacuumeter line for air infiltration, reconnect the vacuumeter and repeat the operation starting from the E) point.




### NOTE

Neither operate on the coupling screw of the throttle shafts and on the control unit trimmer.






## ENGINE OVERHAUL




### Head assy removal



Remove carefully the 8 fixing nuts (1) and the valve cover(2) to avoid any damage to the gasket (3).




Working on the L.H. side of the engine remove the phonic wheel cover and its gasket by acting on the 5 bolts.




Remove the head oil pipe on the front side, by acting on the fixing screws with a 8 T-wrench.  
Rotate the camshaft until the n°1 piston reaches the TDC using a 19 socket wrench on the phonic wheel nut.







## ENGINE OVERHAUL



In this position the "T" notch on the phonic wheel is aligned with the notch on the crankcase.




The N°1 cylinder cams converge to the top symmetrically as shown in picture. The notches on the camshafts control gears are horizontal and face outwards.





Withdraw the central screw of the timing system chain tensioner. Remove the chain tensioner by acting on the 2 fixing screws.

## ENGINE OVERHAUL




First remove the external camshafts U-bolts (4 - 5) by acting on the 4 socket head screws of each one.  
Then remove the internal ones taking care to the valve springs thrust.







TIMING SYSTEM DRIVING PARTS




## ENGINE OVERHAUL



Help if necessary the U-bolt removal using a mallet or carefully the end of a flat screwdriver





Rotate without effort the exhaust side camshaft removing it from its seat, in this way the timing system chain has a lower tension.  
Disentangle the chain from the gear. First remove the exhaust side camshaft and fasten the timing chain with a copper wire to recover it in the next operations.




Remove the intake side camshaft.

Remove the timing chain guide by acting on the fixing screw.






## ENGINE OVERHAUL




Remove the 12 head fixing nuts starting from the external ones: just follow the order shown in picture

**ATTENTION**  
There is a washer on each stud bolt: avoid its fall in the engine; to be sure stop the holes with clean clothes.





## ENGINE OVERHAUL




Remove the head and carefully put it on a clean table.

Don't turn it upside-down.  
Remove the gasket which is going to be replaced at reassembly.




### Head assy inspection

Remove any carbon deposit from the combustion chamber.  
Clean any fouling of the cooling ducts.  
Check any surface for cracks and the seal surfaces for grooves, steps or any other damage.  
Check the mating surfaces for flatness and the spark plug thread condition.



## ENGINE OVERHAUL




### Head assy assembly

To execute this operation you need the following special tool:  
A) n° 94793 piston / cylinder plane distance measuring tool

Place the new gasket on the cylinder plane.  
The gasket is of the same thickness of the one installed before if no parts replacement occurred.


If replacement is necessary you'll need to measure the piston / cylinder plane distance with the n° 94793 tool, tightening the head nuts at 12 Nm.  
The choice is made following the downside table:




Piston / cylinder plane distance	Gasket type
0,37 - 0,57 mm	Thick => 1,45 mm
0,17 - 0,37 mm	Thin => 1,30 mm

You can distinguish gaskets from the hole (1) as shown in picture  
The one with the hole is the thick gasket as in the downside table


HOLES NUMBER	THICKNESS	PART N°
NONE	1.30 ± 0.05 mm	8A0087757
1	1.45 ± 0.05 mm	800087757




## ENGINE OVERHAUL



Install the gasket with the ALTO writing on the upper side and the projection in the running direction  
Install the centering bush between head and cylinder.  
Insert the washers in the stud bolts, using a screwdriver to guide them on the inner stud bolts if necessary  
Apply MOLKOTE HSC antiscuff grease on the nuts thread.  
Don't apply any grease on the stud bolts thread: they have to be clean and degreased.




Tighten the bolts with a setscrew wrench and pre-lock them at a 35 Nm torque.  
Tighten the bolts following the order as shown in picture at a 45 Nm torque.




Pick up the timing chain.  
Insert the timing chain guide with its screw and lock with LOCTITE 242 at a 8 Nm torque after a perfect degreasing.




To obtain a proper timing operate this way:  
Let the n°1 piston reach the TDC: in this position the "T" notch on the phonic wheel is aligned with the notch on the crankcase.  
Remove the copper wire of the timing chain.  
Tighten the timing chain.





# ENGINE OVERHAUL



## ENGINE OVERHAUL




Install the intake camshaft with the timing notch of the drive gear parallel to the head table, facing outside (see picture).

Install the exhaust camshaft with the notch between the 24° and 25° pin of the timing chain.

Start the from the pin after the intake camshaft notch.

Check the proper O-Ring installation under the head U-bolts.




Install the n°2 and n°3 U-bolts, referring to the numbers on the intake side.

Install the n°1 and n°4 U-bolts.

Tighten the socket head screws by hand.

**ATTENTION**  
Check the proper installation of the chain tensioner before the U-bolts screws locking.

**ATTENTION**  
Don't lock the U-bolts screws if their springs are charged. Rotate properly the crankshaft to have the springs of the U-bolt you are acting on are released and the cams are on the basic radius.




Tighten the Allen screws gradually.

Tighten at a 12 Nm torque, starting from the n° 2 and n°3 U-bolts.

Check the valve cover gasket condition.


Apply 5552 silicone gasket on the semicircles of the head (see picture)




Install the valve cover.

Install the screws by hand, then lock them at a 8 Nm torque.

Install the head oil delivery pipe and grease the O-Rings.






## Head parts disassembly

To execute this operation you need the following special tools:

- n°94796 tool for valve removal
- n°95719 tool for cotters removal
- n°94798 tool for stem rubber seal removal tool.





**ATTENTION**  
Each part of a valve (collets ,springs, etc.) must be reinstalled on the same valve


Remove the head following the procedures described in the chapter " Head assy removal"

## Valve removal

- A) Remove the buckets (1) using a magnet and number them with a pen to install them in the same position.
- B) Remove the clearance adjustment shim pads (2) with a magnet and put them in their bell to install them in the same position.  
Use only the n°95179 tool to remove collets to avoid valve bending.
- C) Install the head on the n°94796 tool.
- D) Use a mallet on the upper cap to unlock the collets.
- E) Compress the springs on the upper cap
- F) Remove the collets with a magnet
- G) Carefully release the cap pusher.








## ENGINE OVERHAUL



Now you can remove in sequence:

- A) Collets
- B) The 2 coaxial springs (4 and 5)
- C) Remove if necessary the rubber stem seals using the n°94798 tool
- D) Remove the lower cap and the shim adjustment
- E) Remove the valve from the combustion chamber.





**Valve seat maintenance**

To execute this operation you need the following special tool:

n° 95321 tool: valve seat cutting tools kit

Check the sealing surface [A] between the valve [B] and the seat [C] for cracks or pitting.

Measure the external diameter [D] of the sealing surface on the valve seat. If the value is too wide a repair is needed.

**External diameter of the valve seat sealing surface**

**Standard: exhaust: 24.6<sup>+0,3</sup><sub>+0</sub> mm**  
**intake: 28.6<sup>+0,3</sup><sub>+0</sub> mm**

Measure the sealing width using a painted gauge or Prussian blue. If it is too wide, too thin or uneven, proceed with repair.

**Width of the valve seat sealing surface**

**Standard: exhaust, intake 1<sup>0</sup><sub>-0.3</sub> mm**

Repair by milling the seats with the mills kit: 78° (1), 45° (2), 17° (3)  
 Grind the valves and check the seal.




**ATTENTION**


**Remove as less as possible material from the seat:**

**Intake max 0.6 (vertical)**


**Exhaust max 0.4 (vertical)**



Check intake and exhaust ducts for leaking by filling them with fuel. If leaking occurs check the repair quality with Prussian blue.



# ENGINE OVERHAUL






## Valve seat replacement

To execute this operation you need the following special tools:


- n°95318 punch removal valve seat intake
- n°95319 punch removal valve seat exhaust

Operate like this:

- A) Remove the old seats by milling them carefully to avoid any damage to the seat housing on the head.
- B) Check the housing diameter to choose the new oversize seat with an installation interference of .....
- C) Valve seat are supplied as spare parts with a 0.03 mm oversize of the external diameter.
- D) Slowly and uniformly heat the head at 180° and cool the new seats with dry ice.
- E) Drive the seats in their housing with the punches n°95318 (exhaust) and n°95319 (intake).
- F) Let the head cool, then mill the seats and grind the valves relating to the dimensions below:



Ø A	28.6 <sup>+0.3</sup> <sub>0</sub>
Ø S	24.6 <sup>+0.3</sup> <sub>-0</sub>
[ E ]	1 <sup>+0</sup> <sub>-0.3</sub>



## VALVE GUIDE CONTROL AND MAINTENANCE

To execute this operation you need the following special tools:  
 n°95429 installing valve guides intake  
 n°95320 installing valve guides exhaust

**valve stem - valve guide clearance:**

**mm 0.01-0.03 intake  
 0.02 ÷ 0.04 exhaust**

**coupling limits**

**mm 0.10 intake - 0.12 exhaust**

**Guide internal Ø limit:**

**mm 4,55**


Perform an accurate visual check of the valve guide  
 Measure valve stem - valve guide clearance using the check punch and a micrometer to determine the wear




**NOTE**  
 The check punch (Ø 4.55mm) can't go through the guide hole.




**NOTE**  
 If guide replacement occurs you have to check and replace





## ENGINE OVERHAUL



### Valve guide removal


Remove the valves and the rubber seals as shown before, then proceed like this:

Slowly and uniformly heat the head at 100°.  
Withdraw the valve guide with the n°95320 punch  
Perform an accurate visual check of the valve guide

### Valve guide installation

Install an oversize valve guide proceeding like this:

Oil the valve guide external surface  
Slowly and uniformly heat the head at 180°÷200°.  
Cool the valve guides with dry ice or liquid nitrogen (N2)  
Insert the valve guide up to the sealing using the n°95320 punch and let it rest till the temperature is stabilised.  
Check the valve sliding in the guide and perform one cut with a 4.5 H7 reamer if necessary



### Valve

The valve stem diameter can't be lower than :


**4.485<sup>-2/100</sup> mm intake**

**4.475<sup>-2/100</sup> mm exhaust**

The minimum distance from the seal position at 45° to the valve table can't be lower than 0.8 mm (see picture)

Check the stem and the sealing surface for their good conditions. No sign of pitting, cracks, strain or wear are allowed.

Verify the stem straightness is perfect.



### Valve - Valve guide coupling

The **coupling clearance** at installation is:

**0.01 ÷ 0.03 intake**



**0.02 ÷ 0.04 exhaust**

The maximum coupling clearance is

**0.10 intake**

**0.12 exhaust**

If the clearance is too wide, replace valve and guide.



### Springs

Check the free length is not lower than the limit allowed, replace the springs if necessary:


Inner spring  $l = 30,5$  mm

External spring  $l = 32,6$  mm

Service limit: 30 mm



Service limit: 32,1

## ENGINE OVERHAUL





### Valve assembly

- A) Accurately degrease the guide
- B) Install the shim adjustment and the lower cap (6) check for the tolerance.
- C) Install the rubber wear, always new, on the valve guide with the 95581 tool
- D) Oil the valve stem




Install the valve.





## ENGINE OVERHAUL




Install following the order:

- A) The 2 coaxial springs
- B) The collets in the upper cap housing, the fit of the cap on the springs.
- C) Install the head no the n°94796 tool and compress the springs till the coters installation with the n° 95180 tool.
- D) Carefully use a mallet to set the collets




### NOTE

**Before collets setting ensure the head is not leaning on a table to avoid any damage to the valve there is no problem if the head is mounted on the n° 94796 tool.**



- E) Insert a shim with the right thickness and lubricate its surface
- F) Check for the free revolution of the shim in its seat.
- G) Insert the bucket after the lubrication of its the seat

Install the head following the procedure described in the chapter " Head assy assembly "



### Valve clearance adjustment


Ensure the spark plugs are not installed




### ATTENTION

**If the head is installed on the engine, close the spark plugs housing with clean clothes and install the n°95191 grid to avoid any fall of objects in the timing chain housing**

- A) With a crankshaft revolution, fully release the springs of the valve you are acting on (TDC in compression stroke)





## ENGINE OVERHAUL



B) Measure the valve clearance with a thickness gauge

Intake valve clearance	Exhaust valve clearance
0,15 ÷ 0,20 mm	0,20 ÷ 0,25 mm

- C) Calculate the difference between the obtained clearance "D" and the standard value of the table  
D) Read on the shim the thickness value "S"  
E) Choose a new shim with a "S+D" thickness value



### Chain tensioner

Remove the central screw-cap and withdraw the spring and the pin.

Remove the screws fixing the chain tensioner to the head.

Remove the chain tensioner.

Disassembly the chain tensioner and check the correct working of each part. The internal pin must run clearly and the inner spring must give a quick response.

Replace the assembly in case of malfunction.


If everything works properly lubricate the parts and install the assembly with the chain tensioner in the minimum extension position (all in the main body)


Install the chain tensioner body locking the 2 socket head screws using a T wrench with a 8 Nm torque

Install in this order: the pin in the spring, the spacer and the screw cap.

Lock the screw cap by hand till you feel the tensioner extend, then lock it with a 8 Nm torque

Acting this way the chain tensioner is adjusted.







# ENGINE OVERHAUL



## CYLINDERS AND PISTONS GROUP



## ENGINE OVERHAUL



### Cylinder and piston removal

Remove the head and the rubber pipe connecting cylinder and water pump as described in the specific chapters.

Remove carefully the cylinders block, taking care to avoid any damage to the piston rings.

Operate on a piston at a time during the removal procedure.



First remove the 2 pistons at TDC, then rotate the crankshaft 180° and remove the 2 others.

Remove the piston circlip fixing the pin to the piston.

Withdraw the pin.

Sign the piston crown to remember its position, then remove it

Remove the crankcase - cylinder group gasket.



### Cylinder overhauling

Check the cylinder walls for evidence of seizure.



Check the cylinder ovality proceeding like this:

- Measure the **nominal diameter for each cylinder at a 20 mm distance from the upper edge** as shown in picture
- Repeat the measurement for the other cylinders perpendicularly.
- Ovality** must be **lower than 0.015 mm** (wear limit).

Replace the entire group if just one cylinder is out of range

Replace if necessary pistons and rings too.

There is an identification letter for each cylinder giving the dimension group: you must have, for example, an "A" cylinder coupling with a "A" piston, and so on.



### Piston overhauling


Clean the piston crown from carbon deposit.

Perform an accurate visual check of the piston; no signs of pitting, cracks, strain or wear are allowed.


Measure the piston diameter perpendicularly to the pin axis at the dimension shown in picture.

Replace the piston in case of wear

The piston dimension group must be the same of the cylinder



## ENGINE OVERHAUL



### Cylinder - piston coupling

The piston - cylinder group is supplied matched; if an exchange of piston occurs, verify the coupling clearance.




**Measure the barrel diameter at a 20 mm distance from the upper edge** as shown in picture

**Measure the piston diameter at a 11,5 mm distance from the skirt base**, perpendicularly to the pin axis

Measure at 20°C.

**The piston - cylinder clearance** must be in the range **0.025 ÷ 0.045 mm**.

Wear limit : **0.1 mm**



### Piston pin overhauling


Check the piston pin for scoring or blue signs caused by overheating.

### Piston pin - piston coupling

**The clearance (S)** must be in the range **0.004 ÷ 0.012 mm**.

Wear limit: **0.03 mm**

Replace piston and pin if the coupling exceeds the limit.




### Piston pin - rod small end coupling

**The clearance** must be in the range **0.015 ÷ 0.032 mm**.

Wear limit: **0.04 mm**


## ENGINE OVERHAUL



### Rings

Check the rings for scoring or signs of swell.  
The ring must have a sharp edge and free in its housing.  
The spare part piston are supplied with pin and rings  
In case of rings wear, we recommend to replace the piston too.

RING	Standar	WEAR LIMIT
1°	THK 0.8 <sup>-0.01</sup> <sub>-0.03</sub>	0.75
2°	THK 1 <sup>-0.01</sup> <sub>-0.025</sub>	0.96
SCRAPER	THK 2 <sup>-0</sup> <sub>-0.1</sub>	1.88



### Rings - cylinder coupling

Place the ring perfectly plane at 5 mm from the head table in the cylinder and measure the distance between the ends.

The maximum clearance for each ring is:

N°1 RING: **0.2 ÷ 0.4 mm**

Wear limit: **0.6 mm**

N°2 RING: **0.2 ÷ 0.4 mm**

Wear limit: **0.6 mm**

SCRAPER: **0.2 ÷ 0.7 mm**

Wear limit: **1.0 mm**

### Cylinder and piston installation

Install the rings in the piston with the "Ne Top" writing towards the top, following the order shown in picture.

Oil the rod small end and the gudgeon pin.

Install the inner ring on the piston.

Install the piston with the rings on the rod: the arrow must be on the exhaust side.

Insert the pin up to the beat.

Install the external ring



#### ATTENTION

**Cover the crankcase openings with a clean cloth before the stopper ring installation, to avoid its fall in the oil sump**

Install a new gasket between the crankcase and the cylinder group.

Install the rings on the piston as shown before.


Oil cylinder and rings


Place the pistons n°1 and 4 at TDC then, with a crankshaft rotation, the 2 others always at the TDC.

Install the pistons pushing the rings by hand.


Take maximum care during this operation, due to the rings brittleness.

Let the crankshaft rotate few turns, to check the pistons for their free






CLUTCH



## ENGINE OVERHAUL





The clutch disengagement is obtained with a transmission group made of a thrust piston on the engine left side, with hydraulic drive. This piston pushes a rod controlling the clutch spring plate

### Clutch removal


To execute this operation you need the following special tools:

n° 79015 clutch tool


Remove the 11 screws fixing the clutch cover to the crankcase. Remove the clutch cover and the gasket that is going to be replaced at reassembly.




Remove the 6 screws(1) of the clutch spring plate (2) with its springs




Remove the clutch spring plate.  
Withdraw by hand all the plates (3) you can.  
Straighten the nut (4) tab washer







## ENGINE OVERHAUL




Remove the nut using the n° 79015 tool to stop the clutch hub (5).  
Remove the clutch hub.





Remove the clutch group, the spacer (6) and the shim adjustment washer (7)

**ENGINE OVERHAUL**




Strip the clutch group in the order shown in picture





## ENGINE OVERHAUL





### Clutch overhauling

Check the rod for straightness and wear

Check the friction plates for wear. **The standard thickness is 3 mm**  
Wear limit : **2.8 mm**.

No signs of burning, grooves or other damages are allowed.  
Replace the whole plates group even if only one is damaged.

Put the plate on a table and check the deformation.




Measure the length "L" of the springs with a gauge.

Service limit: **38.8 mm**

Replace the springs exceeding the service limit.



## ENGINE OVERHAUL




### Clutch installation


Assembly the clutch group  
Install the 9 friction plates and the 8 steel plates alternated, starting with a friction plate  
Insert the group following the 3 meshes taking care of the crankshaft one.  
Insert the shim adjustment washer and the spacer.  
We strongly recommend to use a new tab washer at reassembly.  
Lock the nut at a 95 Nm torque and bend the tab washer

**ATTENTION**  
The first 16 plates have a given assembly position but the last one needs a one step rotation.





Install the clutch spring plate, locking the screws with springs at a 10 Nm torque.  
Replace the cover gasket.  
Align the dowel pins.  
Install the cover and tighten the screws by hand.  
Lock them at a 10 Nm torque.






GEAR AND GEAR CONTROL



## ENGINE OVERHAUL






### Gear group removal

Remove the clutch following the procedures described in the chapter "Clutch removal"  
Remove the clutch rod acting on the clutch side

 **NOTE**  
**Only remove push rod from sprocket side**

Remove the 6 screws of the gear cover  
Carefully use a mallet on the drive shaft acting on the clutch side, with a hand on the gear cover till it is shoved off the crankcase.

Remove the gear group



### Gear control


Strip the gear group in the order shown in picture.



Methodically arrange the various parts to make the reassembly easier.

Check every part for damage or wear.

Particularly check the following parts:

- Shift drum
- Drive and output shafts





### Shift drum

Check the shift drum: no signs of wear on the grooves are allowed.


**Fork pin - groove clearance** for new parts: **0,15 ÷ 0,35 mm**

Wear limit: **0,65 mm**


**Groove width** of a new drum: 7,05 ÷ 7,15

Wear limit: 7,35


Verify the working clearance between the fork pin and the shift drum groove, measuring the dimensions with a gauge. If the value exceeds the service limits, compare the standard value to choose the parts to be replaced.



Verify the gear locker pawl free movement. Reassemble the various parts by acting in the opposite way.





## ENGINE OVERHAUL





### Drive and output shafts

**ATTENTION**  
Overhaul the shaft separately  
to avoid any confusion of  
similar parts

Methodically arrange the various parts to  
make the reassembly easier.





**Gear group overhaul**

To execute this operation you need the following special tools:  
n° 94792 gearbox tool

remove the gear group from the engine and install it on the engine simulation tool n° 94792, tightening the pinion locking nut and the nut with spacer simulating the clutch hub.


Check the gears teeth for their perfect condition: they must have sharp edges.

Idle gear must rotate on their shafts easily.

The minimum axial clearance of the idle gears is 0,10 mm

Check the bearings in the gearbox for wear.

Verify the dimensions shown in the picture



**Shift forks**

Check the shift forks for evidence of bending and other damages.



Replace the curved shift forks due to the danger of malfunction of the gear shifting and of the disengagement of the gear under charge. Check with a thickness gauge the fork clearance in the groove of its gear.

Replace the fork or the gear if the clearance is too wide, relating to the given values:


<b>gear groove limit</b>	<b>5.6 mm</b>	<b>drive</b>	
	<b>4.6 mm</b>	<b>output</b>	
<b>fork limit</b>	<b>4.65 mm</b>	<b>drive</b>	<b>5th-6th speed</b>
	<b>3.65 mm</b>	<b>output</b>	<b>1st-2nd.,3rd-4th speed</b>

The forks must slide without stress.

The speed gears must slide without obstacles and without friction





## ENGINE OVERHAUL



### Installation

To execute this operation you need the following special tools:

n° 94792 gearbox tool




Reassembly the various parts by acting in the opposite way.


Install the 2 shafts on the n° 94792 engine simulation tool

Install a shift pedal and check the gear box is correctly working




**ATTENTION**  
Always install a new washer under the pinion at reassembly.






## ENGINE OVERHAUL




The gear engagement and disengagement needs to take place without resistance. If you find any resistance, verify the axial clearance is correct.

Check with a thickness gauge for the **groove - fork clearance** of every engaged gear: **0.2 ÷ 0.3 mm** on both sides of the coupling.

The fork must be free in its movement. Install the gasket on the internal side.



## ENGINE OVERHAUL




Install the gear group in gear in the crankcase to avoid any damage to the neutral switch light.



### **ATTENTION**

**Do not install the gear group in the neutral position  
Install the clutch rod**







# ENGINE OVERHAUL



## CRANKCASE ACCESSORIES



## ENGINE OVERHAUL



Remove the phonic wheel pick-up

### Alternator

- Removal:

Acting on the left side of the engine, remove the 3 locking bolts of the alternator and of the stiffening brace


Withdraw the alternator: avoid any fall of the flexible couplings.

- Installation:

Grease the flexible couplings and the O-Ring.

Insert the blades in the flexible coupling assy.

Approach the screws by hand, then lock at a 25 Nm torque.



### Starting motor

- Removal

Remove the 2 locking screws.



Withdraw the starting motor, paying attention to avoid any damage to the


- O-Ring on the shaft.

Installation:


install the motor on the crankcase

Approach the screws by hand, then lock at the prescribed torque.







OIL PUMP





## ENGINE OVERHAUL




Remove the clutch and the gear as described in the specific chapters.  
Remove the seeger ring and the oil pump gear  
Remove the 3 locking screws.  
Push the oil pump shaft on the transmission side and withdraw the oil pump body by the clutch side.  
Remove the external screws to strip the pump.  
Separate the various parts as shown in picture




Perform an accurate visual check of the parts to find signs of scoring or deformation  
Replace the damaged parts.  
Reassembly the various parts by acting in the opposite way.  
Install the oil pump on the engine.  
Accurately degrease the 3 screws, then lock them at a 10 Nm torque with LOCTITE 242






WATER PUMP




## ENGINE OVERHAUL




### Water pump removal.

**⚠ ATTENTION**  
**Operate with cool engine**

- A) Loosen the clamp and remove with care the pipe coupling, to avoid any damage.
- B) Remove the screws (1) locking the pump to the crankcase.



- C) Remove the pump from the crankcase



### Water pump parts disassembly


Operate this way:


- A) Remove the screws locking the pump body(1) and separate this one from the cover

**● ATTENTION**  
**Do not let the 2 dowl centering bushes (9) fall.**


- B) Remove the 2 O-Rings (2)
- C) Remove the 2 seeger rings (3).
- D) Extract the rotor(4)with the shaft (5).
- E) Separate the rotor(4) and the shaft (5) by unscrewing it.

**⚠ ATTENTION**  
**Use proper precaution during the next operation to avoid scalds**






## ENGINE OVERHAUL



- A) Heat the pump body (1) at 120°C
- B) Extract the 2 bearings (6) and the spacer (7)

- C) Heat at 120°C another time
- D) Withdraw the ring (8)



### Water pump parts overhauling

Check every part for signs of wear

Take a particular care about the bearings smoothness and the O-Ring condition.

Check the rotor for signs of flaws and settling.

The clearance between the rotor shaft and the bearings can't be too wide

Replace the parts with signs of wear

### Water pump parts assembly




#### ATTENTION

**Use proper precaution during the next operation to avoid scalds**

- A) Heat the pump body (1) at 120°C
- B) Withdraw the ring (8)


## ENGINE OVERHAUL



- C) Withdraw the 2 bearings (6) and the spacer (7)
- D) Let the body(1) cool, then withdraw the rotor (4) with its shaft(5)
- E) Withdraw the 2 seeger rings (3).
- F) Withdraw the 2 O-Rings(2)


**ATTENTION**  
Do not let the 2 centering bushes (9) fall.

- G) Tighten the screws locking the pump body(1) and join this one to the cover




### Water pump installation

- A) Install the pump on the crankcase, taking care to avoid damaging the O-Ring of the body
- B) Tighten the screws (1) locking the pump to the crankcase
- C) Install on the crankcase with care the pipe coupling and the clamp.





## ENGINE OVERHAUL



### Start free wheel

Remove the clutch and the gear as described in the specific chapters.  
Withdraw the pin of the intermediate starting gear, removing the pin stopper plate before.

Withdraw the intermediate starting gear

Withdraw the alternator stiffening bracket and the generator shaft.

Remove if necessary the male spring drive from the generator with the n°94794 sprag locking nut tools to unlock the nut

Remove the screw with the n°94795 sprag locking nut tools tool and disassembly the generator shaft

Remove and check the free wheel

Install the free wheel with the seeger ring facing the inner side; install the opened part of the seeger ring at last to make the job easier

The free wheel can **rotate clockwise only**

Install the n°94795 tool on the group and lock the screw at a 25 Nm torque with LOCTITE 242

Install the male spring drive on the generator and lock the nut at a 25 Nm torque with LOCTITE 242




Rotate the oil draining hole of the flange till it faces down.

Lock the screws at a 8 Nm torque with LOCTITE 242.

Install the start gear with the smaller teeth on the speed gear side facing inwards.

Install the pin on the clutch side.

Install the pin stopper plate locking the screw with LOCTITE 242.





### Neutral switch

No maintenance is required.


Replace the switch in case of malfunction

Use a socket spanner, locking at a 10 Nm torque, to install the switch.






CRANKCASE AND CRANKSHAFT



## ENGINE OVERHAUL



### Oil sump

Remove the oil sump by acting on the 6 mm screws

Always replace the gasket at reassembly.

Check the oil filter to find cracks or clefts; clean with low pressure compressed air from inside to outside




To remove the oil filter withdraw the locking screw

Degrease the 2 screws and lock them at a 8 Nm with LOCTITE 242 at reassembly.

Install the gasket and approach the screws by hand.

Lock the screws at a 10 Nm torque.





**Crankshaft removal**

Remove the oil filter and the heat exchanger with its support.  
Remove the following parts as described in the specific chapters:


- A) Head
- B) Cylinders group
- C) Pistons
- D) Clutch
- E) Speed gear

Remove:  
F) The 6 screws, blow-by cover included


**NOTE**  
Do not forget the screw inside the sump

G) The 8 mm screws


**NOTE**  
The screws have the same or much different length, thus, is impossible make a mistake at reassembly.




# ENGINE OVERHAUL



H) Separate the 2 sumps(1 and 2) levering on the 2 relieves



I) Remove the bearings(3)




J) Withdraw the crankshaft

If a temporary half shell bearing brass (4) removal is needed, write on the support and the sump number with a pen

Example:

the half shell bearing brass of the support n°1 (starting from the left) of the upper sump will be written L1

For the couplings, refer to the classes shown downside:  
main bearings selection table



MAIN BEARING SELECTION TABLE					
		CRANKSHAFT SEAT DIAMETER			
		A	38.103 38.111	B	38.112 38.119
MAIN JOURNAL DIAMETER	A	34.981 34.988	1.546 / 1.551 BLUE	1.550 / 1.555 YELLOW	
	B	34.989 34.997	1.542 / 1.547 RED	1.546 / 1.551 BLUE	
		WORKING CLEARANCE 0.012 / 0.038			

## Crankshaft overhaul

Remove the crankshaft and replace the main bearings and the big end bearings in case of doubt about their efficiency.


Check the crankshaft working clearance

**Main bearings working clearance: 0.012 ÷ 0.038**


Wear limit: **0.06 mm**

**Big end bearings working clearance: 0.036 ÷ 0.061**

Wear limit: **0.08 mm**




## ENGINE OVERHAUL




### Crankshaft installation


Degrease and clean all the paste residuals  
Install the bearings in the crankcase without lubrication



Lubricate the bearings on site



Lubricate the n°5 support side as it works for the camshaft centering




Install a new cap on the right side with silicone paste on its surface, between the cap and the crankcase




Install the crankshaft


## ENGINE OVERHAUL




Check with a thickness gauge the **axial clearance** of the crankshaft with the main bearing: the right value is **0.2 mm**.  
If you find a different value please contact MvAgusta motor S.p.A.




Install the bearings on the lower crankcase with the stoppers facing each other and inside the crankcase.



Install the centering bushes on the lower crankcase.  
A layer of a THREEBOND 1215 gasket on the mating surfaces of the upper and lower crankcases  
Proceed to the assembling of the crankcases, carefully using a mallet up to the complete closing.






Install the 12 8 mm screws by hand, then lock them at the prescribed torque.  
Install the remaining 6 mm screws by hand, then lock them at the prescribed torque.



**ATTENTION**  
**Lock the screws inverting the removing order**

Install the heat exchanger with the O-Ring and lock the support screws at a 10 Nm torque, the exchanger aluminium screw at a 14 Nm torque.  
Always replace the aluminium seal washer at reassembly  
Install the oil filter lubricating the gasket with engine oil and locking by hand

## ENGINE OVERHAUL




### Rod disassembly

Remove the crankshaft, following the described procedure  
 Place the crankshaft with the rods facing down  
 Operate separately on every rod  
 Remove the 2 screws locking the small end and the big end, supporting the rod



**NOTE**  
**Reassembly every rod before acting on the next.**



### Shell removal

Disassemble the rod and remove the bearings from the big end and the small end

### Crank pin - brasses coupling



If replacement occurs check the dimension of the rod and of the pin, referring to the table below, choose the bearings by colour  
 Measure on the primary axis, with the screws locked at a 35 Nm torque.  
 If replacement is needed, simply follow the indicated letter the class of the rod and of the bearing.

### Bearings installation

Install the bearing half shells on the big end and the small end  
 Lock at a 25 Nm + 25° torque

Always use new screws even if the rod is not.

BIG END BEARING SELECTION TABLE					
		BIG END DIAMETER			
		A	38.114 38.122	B	38.123 38.130
ROD JOURNAL DIAMETER	A	34.981 34.988	1.450 / 1.545 BLUE	1.544 / 1.549 YELLOW	
	B	34.989 34.997	1.536 / 1.541 RED	1.540 / 1.545 BLUE	
		WORKING CLEARANCE 0.036 / 0.061			




### Timing chain inspection and installation

Check the wear of every part of the timing drive system (gears and chain) at engine overhaul.

If the gear teeth are worn out replace all the parts.

Replace the timing chain at the prescribed mile-age.



**ATTENTION**  
If the wear of a timing part exceeds the prescribed limit, check the entire group and replace the parts if necessary.



Rotate the camshaft until the n°1 piston reaches the TDC, using a 19 socket wrench on the phonic wheel nut.

In this position the "T" notch on the phonic wheel is aligned with the notch on the crankcase.

The N°1 cylinder cams converge to the top symmetrically as shown in picture. The notches on the camshafts control gears are horizontal and face outside.



Place the round sign on the intermediate timing gear aligned with the notch on the head.

Install the timing chain but fasten it with a copper wire to recover it if necessary.

Check the sign position on the gear (aligned with the notch on the head)  
Install the pin and lock it with the seeger ring.