

# 23. INDEX

ABSOLUTE PRESSURE FUEL SUPPLY SYSTEM .....	2-2
AIR CLEANER .....	4-6
AIR CLEANER HOUSING .....	6-64
AIR DUCT COVERS .....	3-9
ALTERNATOR CHARGING COIL .....	17-9
ALTERNATOR COVER INSTALLATION .....	11-7
ALTERNATOR COVER REMOVAL .....	11-4
BANK ANGLE SENSOR .....	6-93
BATTERY .....	17-5
BATTERY TRAY .....	17-7
BATTERY/CHARGING SYSTEM SPECIFICATIONS .....	1-10
BODY PANEL LOCATIONS .....	3-2
BRAKE FLUID .....	4-25
BRAKE FLUID REPLACEMENT/AIR BLEEDING .....	16-6
BRAKE LIGHT SWITCH .....	
LIGHTS/METERS/SWITCHES .....	20-21
MAINTENANCE .....	4-27
BRAKE PAD WEAR .....	4-26
BRAKE PAD/DISC .....	16-9
BRAKE PEDAL .....	16-29
BRAKE SYSTEM .....	4-26
BRAKE/TAIL LIGHT .....	20-9
CABLE & HARNESS ROUTING .....	1-22
CAM CHAIN TENSIONER LIFTER .....	9-34
CAM PULSE GENERATOR .....	6-90
CAMSHAFT INSTALLATION .....	9-26
CAMSHAFT REMOVAL .....	9-8
CHARGING SYSTEM INSPECTION .....	17-9
CLUTCH .....	10-7
CLUTCH SWITCH .....	20-21
CLUTCH SYSTEM .....	4-28
CLUTCH/STARTER CLUTCH/	
GEARSHIFT LINKAGE SPECIFICATIONS .....	1-7
COMBINATION METER .....	20-11
COMPONENT LOCATION .....	
ALTERNATOR .....	11-2
CLUTCH/STARTER CLUTCH/	
GEARSHIFT LINKAGE .....	10-2
CRANKCASE/TRANSMISSION .....	12-2
CRANKSHAFT/PISTON/CYLINDER .....	13-2
CYLINDER HEAD/VALVES .....	9-2
ENGINE REMOVAL/INSTALLATION .....	8-2
FRONT WHEEL/SUSPENSION/STEERING .....	14-2
FUEL SYSTEM (Programmed Fuel Injection) .....	6-2
HYDRAULIC BRAKE .....	16-2
REAR WHEEL SUSPENSION .....	15-2
COOLANT REPLACEMENT .....	7-6
COOLING SYSTEM .....	4-19
COOLING SYSTEM SPECIFICATIONS .....	1-6
CRANKCASE ASSEMBLY .....	12-16
CRANKCASE SEPARATION .....	12-5
CRANKCASE/TRANSMISSION SPECIFICATIONS .....	1-8
CRANKPIN BEARING .....	13-11
CRANKSHAFT .....	13-5
CRANKSHAFT/PISTON/CYLINDER SPECIFICATIONS .....	1-8
CYLINDER COMPRESSION TEST .....	9-6
CYLINDER HEAD ASSEMBLY .....	9-22
CYLINDER HEAD COVER ASSEMBLY .....	9-31
CYLINDER HEAD COVER DISASSEMBLY .....	9-7
CYLINDER HEAD COVER INSTALLATION .....	9-32
CYLINDER HEAD COVER REMOVAL .....	9-6
CYLINDER HEAD DISASSEMBLY .....	9-15
CYLINDER HEAD INSPECTION .....	9-16
CYLINDER HEAD INSTALLATION .....	9-24
CYLINDER HEAD REMOVAL .....	9-13
CYLINDER HEAD/VALVES SPECIFICATIONS .....	1-7
DIODE .....	19-14
DRIVE CHAIN .....	4-21
DTC CODE INDEX .....	6-33

DTC TROUBLESHOOTING .....	6-37
DUAL SEQUENTIAL FUEL INJECTION SYSTEM	
(PGM-DSFI) .....	2-3
ECT SENSOR .....	
LIGHT/METER/SWITCH .....	20-16
ECT/THERMO SENSOR .....	
FUEL SYSTEM (Programmed Fuel Injection) .....	6-89
ELECTRIC STARTER SPECIFICATIONS .....	1-10
EMISSION CONTROL INFORMATION LABELS	
(U.S.A. only) .....	1-39
EMISSION CONTROL SYSTEMS .....	1-36
ENGINE & FRAME TORQUE VALUES .....	1-12
ENGINE CONTROL MODULE (ECM)	
FUEL SYSTEM (Programmed Fuel Injection) .....	6-94
ENGINE DOES NOT STAR OR IS HARD TO START .....	22-2
ENGINE IDLE SPEED .....	4-18
ENGINE INSTALLATION .....	8-10
ENGINE LACKS POWER .....	22-3
ENGINE OIL/OIL FILTER .....	4-15
ENGINE REMOVAL .....	8-5
ENGINE STOP RELAY .....	6-94
EVAP PURGE CONTROL VALVE .....	
(California type only) .....	6-98
EVAPORATIVE EMISSION CONTROL SYSTE	
(CALIFORNIA TYPE ONLY) .....	4-20
EXHAUST PIPE .....	3-24
FAN CONTROL RELAY .....	7-18
FAST IDLE WAX UNIT .....	6-81
FLYWHEEL .....	11-5
FORK .....	14-18
FRONT BRAKE CALIPERS .....	16-22
FRONT FENDER .....	3-15
FRONT MASTER CYLINDER .....	16-13
FRONT WHEEL .....	14-12
FRONT WHEEL/SUSPENSION/STEERING	
SPECIFICATIONS .....	1-9
FUEL CUT-OFF RELAY .....	6-60
FUEL LEVEL SENSOR .....	20-18
FUEL LINE .....	4-5
FUEL LINE INSPECTION .....	6-56
FUEL PUMP UNIT .....	6-58
FUEL SYSTEM (Programmed Fuel Injection)	
SPECIFICATIONS .....	1-6
FUEL TANK .....	6-61
FUEL TANK COVER .....	3-15
GEARSHIFT LINKAGE .....	10-22
GENERAL SPECIFICATIONS .....	1-4
HANDLEBAR SWITCHES .....	20-20
HANDLEBARS .....	14-7
HEADLIGHT .....	20-6
HEADLIGHT AIM .....	4-28
HEADLIGHT RELAY .....	20-25
HORN .....	20-24
HYDRAULIC BRAKE SPECIFICATIONS .....	1-10
IAT SENSOR .....	6-89
IGNITION PULSE GENERATOR .....	18-7
IGNITION SWITCH .....	20-19
IGNITION SYSTEM INSPECTION .....	18-5
IGNITION SYSTEM SPECIFICATIONS .....	1-10
IGNITION TIMING .....	18-7
LICENCE LIGHT .....	20-10
LIGHTS .....	20-2
LIGHTS/METERS/SWITCHES .....	20-2
LIGHTS/METERS/SWITCHES SPECIFICATIONS .....	1-11
LOWER COWLS .....	3-6
LOWER INJECTOR .....	6-79
LUBRICATION & SEAL POINTS .....	1-19
LUBRICATION SYSTEM DIAGRAM .....	5-2
LUBRICATION SYSTEM SPECIFICATIONS .....	1-6

## INDEX

- MAIN JOURNAL BEARING..... 13-8  
MAINTENANCE SCHEDULE..... 4-4  
MAP SENSOR..... 6-88  
MIDDLE COWLS..... 3-7  
MIL CODE INDEX..... 6-12  
MIL TROUBLESHOOTING..... 6-15  
MODEL IDENTIFICATION..... 1-2  
MUFFLER..... 3-20  
NEUTRAL SWITCH..... 20-22  
NUTS, BOLTS, FASTENERS..... 4-33  
O2 SENSOR (California type only)..... 6-99  
OIL COOLER..... 5-12  
OIL PRESSURE INSPECTION..... 5-5  
OIL PRESSURE SWITCH..... 20-16  
OIL PUMP..... 5-8  
OIL STRAINER/PRESSURE RELIEF VALVE..... 5-6  
PAIR CONTROL SOLENOID VALVE..... 6-96  
PASSENGER SEAT..... 3-4  
PGM-FI SELF-DIAGNOSIS INFORMATION..... 6-8  
PISTON/CYLINDER..... 13-13  
POOR HANDLING..... 22-6  
POOR PERFORMANCE AT HIGH SPEED..... 22-6  
POOR PERFORMANCE AT LOW AND IDLE SPEED..... 22-5  
POSITION LIGHT..... 20-7  
RADIATOR..... 7-10  
RADIATOR COOLANT..... 4-18  
RADIATOR RESERVE TANK..... 7-17  
REAR BRAKE CALIPER..... 16-26  
REAR COWL..... 3-5  
REAR FENDER..... 3-16  
REAR MASTER CYLINDER..... 16-18  
REAR WHEEL..... 15-8  
REAR WHEEL/SUSPENSION SPECIFICATIONS..... 1-9  
REGULATOR/RECTIFIER..... 17-10  
RIGHT CRANKCASE COVER INSTALLATION..... 10-24  
RIGHT CRANKCASE COVER REMOVAL..... 10-5  
SEAT..... 3-4  
SEAT RAIL..... 3-18  
SECONDARY AIR SUPPLY SYSTEM..... 4-19  
SERVICE INFORMATION  
    ALTERNATOR..... 11-3  
    BATTERY/CHARGING SYSTEM..... 17-3  
    CLUTCH/STARTER CLUTCH/  
    GEARSHIFT LINKAGE..... 10-3  
    COOLING SYSTEM..... 7-3  
    CRANKCASE/TRANSMISSION..... 12-3  
    CRANKSHAFT/PISTON/CYLINDER..... 13-3  
    CYLINDER HEAD/VALVES..... 9-3  
    ELECTRIC STARTER..... 19-3  
    ENGINE REMOVAL/INSTALLATION..... 8-3  
    FRAME/BODY PANELS/EXHAUST SYSTEM..... 3-3  
    FRONT WHEEL/SUSPENSION/STEERING..... 14-3  
    FUEL SYSTEM (Programmed Fuel Injection)..... 6-3  
    HYDRAULIC BRAKE..... 16-4  
    IGNITION SYSTEM..... 18-3  
    LIGHTS/METERS/SWITCHES..... 20-3  
    LUBRICATION SYSTEM..... 5-3  
    MAINTENANCE..... 4-2  
    REAR WHEEL SUSPENSION..... 15-3  
SERVICE RULES..... 1-2  
SHIFT FORK/SHIFT DRUM/TRANSMISSION..... 12-7  
SHOCK ABSORBER..... 15-15  
SIDE COVERS..... 3-4  
SIDE STAND..... 4-29  
SIDE STAND SWITCH..... 20-22  
SPARK PLUG..... 4-7  
SPEEDOMETER/VEHICLE SPEED SENSOR..... 20-13  
STANDARD TORQUE VALUES..... 1-12  
STARTER CLUTCH..... 10-17  
STARTER MOTOR..... 19-6  
STARTER RELAY SWITCH..... 19-12  
STARTER VALVE..... 6-82  
STARTER VALVE SYNCHRONIZATION..... 6-86  
STATOR..... 11-4  
STEERING HEAD BEARINGS..... 4-34  
STEERING STEM..... 14-27  
SUSPENSION..... 4-29  
SUSPENSION LINKAGE..... 15-18  
SWINGARM..... 15-21  
SYSTEM DIAGRAM  
    BATTERY/CHARGING SYSTEM..... 17-2  
    ELECTRIC STARTER..... 19-2  
    FUEL SYSTEM (Programmed Fuel Injection)..... 6-7  
    IGNITION SYSTEM..... 18-2  
SYSTEM FLOW PATTERN..... 7-2  
SYSTEM LOCATION  
    FUEL SYSTEM (Programmed Fuel Injection)..... 6-6  
    LIGHTS/METERS/SWITCHES..... 20-2  
SYSTEM TESTING..... 7-5  
TACHOMETER..... 20-14  
THERMOSTAT..... 7-8  
THROTTLE BODY..... 6-72  
THROTTLE OPERATION..... 4-6  
TP SENSOR..... 6-91  
TROUBLESHOOTING  
    BATTERY/CHARGING SYSTEM..... 17-4  
    CLUTCH/STARTER CLUTCH/  
    GEARSHIFT LINKAGE..... 10-4  
    COOLING SYSTEM..... 7-4  
    CRANKCASE/TRANSMISSION..... 12-4  
    CRANKSHAFT/PISTON/CYLINDER..... 13-4  
    CYLINDER HEAD/VALVES..... 9-5  
    ELECTRIC STARTER..... 19-4  
    FRAME/BODY PANELS/EXHAUST SYSTEM..... 3-3  
    FRONT WHEEL/SUSPENSION/STEERING..... 14-6  
    FUEL SYSTEM (Programmed Fuel Injection)..... 6-5  
    HYDRAULIC BRAKE..... 16-5  
    IGNITION SYSTEM..... 18-4  
    LIGHTS/METERS/SWITCHES..... 20-5  
    LUBRICATION SYSTEM..... 5-4  
    REAR WHEEL SUSPENSION..... 15-7  
TURN SIGNAL..... 20-8  
TURN SIGNAL RELAY..... 20-24  
UNIT PROLINK SUSPENSION..... 2-4  
UPPER COWL..... 3-9  
UPPER INJECTOR..... 6-67  
VALVE CLEARANCE..... 4-11  
VALVE GUIDE REPLACEMENT..... 9-19  
VALVE SEAT INSPECTION/REFACING..... 9-19  
WATER PUMP..... 7-15  
WHEELS/TIRES..... 4-33  
WIRING DIAGRAMS  
    A, AC type..... 21-3