

5. ENGINE REMOVAL/INSTALLATION

ENGINE REMOVAL/INSTALLATION

SERVICE INFORMATION..... 5-1

ENGINE REMOVAL..... 5-2

ENGINE INSTALLATION..... 5-4

5. ENGINE REMOVAL/INSTALLATION


SERVICE INFORMATION

GENERAL INSTRUCTIONS

- Parts requiring engine removal for servicing:
 - Crankcase
 - Crankshaft

TORQUE VALUES

Engine mounting bolt	4.5_	5.5kg-m
Engine hanger bracket bolt	4.5_	5.5kg-m
Rear shock absorber lower mount bolt	2.4_	3.0kg-m
Rear shock absorber upper mount bolt	3.5_	4.5kg-m



5. ENGINE REMOVAL/INSTALLATION


ENGINE REMOVAL

Remove the frame body cover. (⇒2-5)

Remove the two bolts attaching the air cleaner case.

Loosen the band between the air cleaner and carburetor to remove the air cleaner case.

Remove the carburetor cap.




Disconnect the oil pump control cable from the pump body.

Disconnect the oil inlet line from the oil pump.

*

After the oil inlet line is disconnected, plug the oil line opening to prevent oil from flowing out.

Disconnect the auto bystarter, A.C. generator and starter motor wire connectors.



Remove the spark plug cap.




5. ENGINE REMOVAL/INSTALLATION

Remove the rear brake adjusting nut and disconnect the brake cable from the crankcase.

Remove the rear brake cable clamp and rear brake cable.

Remove the cooling air tube band on the left crankcase cover and disconnect the cooling air tube.

Remove the rear shock absorber lower mount bolt.



Remove the right and left engine mounting nuts.

Take out the right and left engine mounting bolts.

Lift the frame upward to separate it from the engine and be careful not to damage .




ENGINE HANGER BRACKET REMOVAL

Remove the engine hanger bracket bolt and engine hanger bracket.

The installation sequence is the reserve of removal.


Torque:4.5_ 5.5kg-m



5. ENGINE REMOVAL/INSTALLATION

ENGINE HANGER BRACKET INSPECTION

Inspect the stopper rubbers and bushings for damage and replace with new ones if necessary.



ENGINE INSTALLATION

Install the engine in the reverse order of removal.


*

Cables and wires should be routed properly.

Torque Values:

Engine mounting bolt : 4.5_ 5.5kg-m

Rear shock absorber lower mount bolt:
: 2.4_ 3.0kg-m



Perform the following inspections and adjustments after installation.

- Throttle cable
- Oil pump control cable (⇒3-11)
- Rear brake cable (⇒3-5)
- Oil pump bleeding (⇒4-5)

