

5. FUEL SYSTEM

5

FUEL SYSTEM

SERVICE INFORMATION -----	5- 2
TROUBLESHOOTING -----	5- 2
THROTTLE VALVE DISASSEMBLY/CARBURETOR REMOVAL-	5- 3
AUTO BYSTARTER-----	5- 6
FLOAT/FLOAT VALVE/JETS -----	5- 8
CARBURETOR INSTALLATION -----	5-11
AIR SCREW ADJUSTMENT -----	5-12
REED VALVE-----	5-13
FUEL TANK-----	5-14
FUEL VALVE REMOVAL -----	5-15
AIR CLEANER -----	5-15

5. FUEL SYSTEM

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- When working with gasoline, keep away from sparks and flames..
- Note the locations of O-rings when disassembling and replace them with new ones during assembly.
- All cables, fuel lines and wires must be routed and secured at correct locations.
- Bleed air from the oil lines whenever they are disconnected.

SPECIFICATIONS

SPECIFICATIONS	MX'er 50
Venturi dia.	14mm
Identification number	PB
Float level	16.3mm
Main jet	#78
Slow jet	#40
Air screw opening	2 ± _
Idle speed	2000±100rpm
Throttle grip free play	1_ 4mm

SPECIAL TOOL

Float level gauge

TROUBLESHOOTING

Engine does not start

- No fuel in tank
- Too much fuel getting to cylinder
- Clogged fuel filter
- Clogged air cleaner

Lean mixture

- Clogged fuel jets
- Clogged fuel cap vent
- Clogged fuel filter
- Bent, kinked or restricted fuel line

- Faulty float valve
- Float level too low
- Clogged air cleaner

Engine idles roughly, stalls or runs poorly

- Incorrect idle speed
- Ignition malfunction
- Compression too low
- Incorrectly adjusted air screw
- Incorrect float level
- Clogged air cleaner
- Intake air leaks
- Fuel contaminated
- Faulty reed valve
- Clogged fuel jets

Rich mixture

- Faulty float valve
- Float level too high
- Clogged air jets


5. FUEL SYSTEM

THROTTLE VALVE DIS-ASSEMBLY/CARBURETOR REMOVAL


Loosen the carburetor cap and remove the throttle valve.



Disconnect the throttle cable from the throttle valve.




Remove the throttle valve spring, carburetor cap and rubber seal.



5. FUEL SYSTEM


Remove the jet needle by removing the needle clip.
Check the jet needle and throttle valve for wear or damage.




THROTTLE VALVE INSTALLATION

Install the jet needle on the throttle valve and secure with the needle clip.

Install the rubber seal on the throttle cable and then install the carburetor cap and throttle valve spring.



Connect the throttle cable to the throttle valve.



5. FUEL SYSTEM

Install the throttle valve by aligning the groove in the throttle valve with the throttle stop screw.



Tighten the carburetor cap.
After installation, perform the following adjustments and inspections.


- Throttle cable free play (⇒3-3)
- Idle speed adjustment (⇒3-7)

Install the met-in box.



CARBURETOR REMOVAL

Remove the air cleaner by removing the air cleaner band screw and attaching bolts.
Disconnect the fuel tube.
Loosen the drain bolt to drain fuel from the carburetor.
Disconnect the auto bystarter wire connector.



5. FUEL SYSTEM

Remove the two carburetor lock nuts.
Remove the carburetor.



Nuts

AUTO BYSTARTER

AUTO BYSTARTER INSPECTION

Measure the resistance between the auto bystarter wire terminals.


Resistance: 5 Ω (10 minutes minimum after stopping the engine)

If the resistance exceeds 5 Ω , replace the auto bystarter with a new one.



After the engine stops for 30 minutes, connect a hose to the fuel enriching circuit and blow the hose with mouth.

If air cannot be blown into the hose (clogged), the auto bystarter is faulty. Replace it with a new one.




5. FUEL SYSTEM

Connect the auto bystarter yellow wire to the battery positive (+) terminal and green/black wire to the battery negative (-) terminal and wait 5 minutes.

Connect a hose to the fuel enriching circuit and blow the hose with mouth.


If air can be blown into the hose, the auto bystarter is faulty and replace it with a new one.



AUTO BYSTARTER REMOVAL


Remove the auto bystarter cover.

Remove the two auto bystarter set plate screws to remove the auto bystarter.



Check the auto bystarter valve and needle for wear or damage.


Check the O-ring for wear or damage.



5. FUEL SYSTEM


AUTO BYSTARTER INSTALLATION

Install the auto bystarter into the carburetor body until it bottoms..
Install the set plate and then tighten the two screws.




FLOAT/FLOAT VALVE/JETS FLOAT CHAMBER

Remove the two float chamber screws and the float chamber.




Remove the screw and O-ring.
Remove the float pin, float and float valve.



5. FUEL SYSTEM

FLOAT/FLOAT VALVE INSPECTION

Inspect the float for damage or fuel inside the float.
Check the float valve seat for wear or damage.




JETS/SCREWS REMOVAL

Before removing the throttle stop screw or air screw, record the number of rotations until it seats lightly. Then, remove them.

⚠ Do not force the air screw against its seat to prevent damage.

Remove the main jet and needle jet holder.



CARBURETOR PASSAGES CLEANING

Blow compressed air through all passages of the carburetor body with an air gun.




5. FUEL SYSTEM


FLOAT CHAMBER ASSEMBLY

Install the main jet and needle jet holder.
Install the air screw and throttle stop screw according to the rotations recorded.

ⓘ If the air screw must be replaced, be sure to perform the air screw adjustment again.



Install the float valve, float and float pin.
Tighten the float screw securely.




FLOAT LEVEL INSPECTION

Slightly tilt the carburetor and measure the float level with the float valve just connecting the float arm.

Float Level: 8.6mm

Replace the float if the level is out of the specified level range.
Install the O-ring.
Check the operation of the float and install the float chamber.
Tighten the screws.




5. FUEL SYSTEM

CARBURETOR INSTALLATION

- ⓘ When installation, do not allow foreign particles to enter the carburetor.


Check the carburetor insulator and O-ring for wear or damage.




Install the carburetor and insulator onto the intake manifold and tighten the two lock nuts.

Connect the fuel tube and auto bystarter wire connector.

- ⓘ Route the auto bystarter wire correctly and properly.



Install the carburetor cap. (⇒5-4)
Install the fuel tube
Install the air cleaner onto the carburetor and tighten the band screw.




5. FUEL SYSTEM

AIR SCREW ADJUSTMENT

Turn the air screw clockwise until it seats lightly and back it to the specification given.

⚠ Do not force the air screw against its seat to prevent damage.

Start the engine and turn the air screw in or out slowly to obtain the highest engine speed.



Throttle Stop Screw

Turn the throttle stop screw to obtain the specified idle speed.

Idle Speed: 2000±100rpm

Air Screw Opening: 2 ± _ turns

Slightly increase the engine speed and make sure that the engine does not miss or run erratic.


If the adjustment of the air screw within the range of ±_ turn makes no difference to the engine performance, check other related items.

5. FUEL SYSTEM

REED VALVE

REMOVAL

Remove the four intake manifold bolts and gasket.
Remove the reed valve and gasket.




INSPECTION

Check the reed valve for damaged or weak reeds.
Check the reed valve seat for cracks, damage or clearance between the seat and reed.
Replace the valve if necessary.



Do not disassemble or bend the reed stopper. To do so can cause loss of engine power and engine damage. If any of the stopper, reed or valve seat is faulty, replace them as unit.



INSTALLATION

Install the reed valve in the reverse order of removal.



Install a new gasket with the gasket indentation aligned with the reed valve.
After installation, check for intake air leaks.

5. FUEL SYSTEM


FUEL TANK

FUEL TANK REMOVAL


Warning

- Keep sparks and flames away from the work area.
- Wipe off any spilled gasoline.


Remove the seat.
Remove the center cover.
Remove the right and left front fender.



Remove two bolts on the end of the fuel tank.




Switch the fuel valve "OFF".
Disconnect the fuel tubes.
Remove the fuel tank and fuel valve.




5. FUEL SYSTEM

FUEL VALVE REMOVAL

Disconnect the fuel tubes and remove the bolts.



Remove the fuel valve and fuel cup.




Remove the screw on the fuel valve control switch.
Remove the two screws on the fuel valve body.

INSPECTION

Inspect the fuel valve strainer for dirt and clog. Clean if necessary.

Replace the O-rings with new ones if they are damaged or deteriorated.



AIR CLEANER

REMOVAL

Remove the five screws on the air cleaner case cover and the cover.

Remove the air cleaner screen and element.

