


1. GENERAL INFORMATION

ENGINE SERIAL NUMBER	1- 1	LUBRICATION POINTS.....	1-13
SPECIFICATIONS	1- 2	CABLE & HARNESS ROUTING.....	1-15
SERVICE PRECAUTIONS.....	1- 3	WIRING DIAGRAM.....	1-20
TORQUE VALUES	1-11	TROUBLESHOOTING.....	1-21
TOOLS.....	1-12		

ENGINE SERIAL NUMBER



Location of Engine Serial Number

1. GENERAL INFORMATION

SPECIFICATIONS

Name & Model No.			SD25AA		
Motorcycle Name & Type					
Overall length (mm)			1820		
Overall width (mm)			685		
Overall height (mm)			1095		
Wheel base (mm)			1215		
Engine type			O.H.C.		
Displacement (cc)			124		
Fuel Used			92# unleaded gasoline		
Net weight (kg)		Front wheel	38.5		
		Rear wheel	63.5		
		Total	102.0		
Gross weight(kg)		Front wheel	67.5		
		Rear wheel	158.0		
		Total	225.5		
Tires		Front wheel	100-90-10		
		Rear wheel	100-90-10		
Ground clearance (mm)			123		
Performance	Braking distance (m)		13 (Initial speed 20km/h 1 rider)		
	Min. turning radius (m)		1.866		
Engine	Starting system		Starting motor & kick starter		
	Type		Gasoline, 4-stroke		
	Cylinder arrangement		Single cylinder		
	Combustion chamber type		Semi-sphere		
	Valve arrangement		O.H.C., chain drive		
	Bore x stroke (mm)		52.4 x 57.8		
	Compression ratio		9.2:1		
	Compression pressure (kg/cm ² -rpm)		12.8□570		
	Max. output (ps/rpm)		9.34/7500		
	Max. torque (kg m/rpm)		1.01/5500		
	Port timing	Intake (1mm)	Open	0° BTDC	
			Close	25° ABDC	
		Exhaust (1mm)	Open	33° BBDC	
			Close	0° TDC	
	Valve clearance (cold) (mm)		Intake	0.12	
			Exhaust	0.12	
	Idle speed (rpm)			1700rpm	
Lubrication System	Lubrication type		Forced pressure & wet sump		
	Oil pump type		Inner/outer rotor type		
	Oil filter type		Full-flow filtration		
	Oil capacity		0.9 liter		


Cooling Type		Forced air cooling	

Fuel System	Air cleaner type & No			Paper element, wet		
	Fuel capacity			7.8 liters		
	Carburetor	Type		VE45		
		Piston dia. (mm)		24		
		Venturi dia.(mm)		22.1 equivalent		
		Throttle type		Butterfly type		
Electrical	Ignition System	Type		CDI		
		Ignition timing		13±3°BTDC/1700rp		
		Contact breaker		Non-contact point type		
		Spark plug		NGK ND C6HSA U20FS-U C7HSA U22FS-U C8HSA U24FS-U		
		Spark plug gap		0.6 0.7mm		
	Battery	Capacity		12V9AH		
	Power Drive System	Clutch	Type		Dry multi-disc clutch	
Transmission Gear		Type		Non-stage transmission		
		Operation		Automatic centrifugal type		
Reduction Gear		Type		Two-stage reduction		
		Reduction ratio	1st	2.8		
	2nd		3.076			
Moving Device	Front Axle	Caster angle		27°		
		Trail length		80mm		
	Tire pressure (kg/cm≤)		Front	1.75		
			Rear	2.00 (2.25)		
	Turning angle		Left	45°		
			Right	45°		
Brake system type			Front	Disk brake		
			Rear	Drum brake		
Damping Device	Suspension type		Front	Telescope		
			Rear	Swing arm		
	Shock absorber type		Front	Telescope		
			Rear	Swing arm		
Frame type				Steel pipe		


1. GENERAL INFORMATION

SERVICE PRECAUTIONS

- Make sure to install new gaskets, O-rings, circlips, cotter pins, etc. when reassembling.



- When tightening bolts or nuts, begin with larger-diameter to smaller ones at several times, and tighten to the specified torque diagonally.



- Use genuine parts and lubricants.



- When servicing the motorcycle, be sure to use special tools for removal and installation.




- After disassembly, clean removed parts. Lubricate sliding surfaces with engine oil before reassembly.




1. GENERAL INFORMATION

- Apply or add designated greases and lubricants to the specified lubrication points.




- After reassembly, check all parts for proper tightening and operation.




- When two persons work together, pay attention to the mutual working safety.



- Disconnect the battery negative (-) terminal before operation.
- When using a spanner or other tools, make sure not to damage the motorcycle surface.




- After operation, check all connecting points, fasteners, and lines for proper connection and installation.
- When connecting the battery, the positive (+) terminal must be connected first.
- After connection, apply grease to the battery terminals.
- Terminal caps shall be installed securely.



1. GENERAL INFORMATION


- If the fuse is burned out, find the cause and repair it. Replace it with a new one according to the specified capacity.



- After operation, terminal caps shall be installed securely.




- When taking out the connector, the lock on the connector shall be released before operation.



- Hold the connector body when connecting or disconnecting it.
- Do not pull the connector wire.




- Check if any connector terminal is bending, protruding or loose.




1. GENERAL INFORMATION


- The connector shall be inserted completely.
- If the double connector has a lock, lock it at the correct position.
- Check if there is any loose wire.
- Before connecting a terminal, check for damaged terminal cover or loose negative terminal.




- Check the double connector cover for proper coverage and installation.



- Insert the terminal completely.
- Check the terminal cover for proper coverage.
- Do not make the terminal cover opening face up.




- Secure wire harnesses to the frame with their respective wire bands at the designated locations. Tighten the bands so that only the insulated surfaces contact the wire harnesses.




1. GENERAL INFORMATION

- After clamping, check each wire to make sure it is secure.


- Do not squeeze wires against the weld or its clamp.




- After clamping, check each harness to make sure that it is not interfering with any moving or sliding parts.



- When fixing the wire harnesses, do not make it contact the parts which will generate high heat.




- Route wire harnesses to avoid sharp edges or corners. Avoid the projected ends of bolts and screws.
- Route wire harnesses passing through the side of bolts and screws. Avoid the projected ends of bolts and screws.




1. GENERAL INFORMATION


- Route harnesses so they are neither pulled tight nor have excessive slack.




- Protect wires and harnesses with electrical tape or tube if they contact a sharp edge or corner.




- When rubber protecting cover is used to protect the wire harnesses, it shall be installed securely.



- Do not break the sheath of wire.
- If a wire or harness is with a broken sheath, repair by wrapping it with protective tape or replace it.




- When installing other parts, do not press or squeeze the wires.



1. GENERAL INFORMATION


- After routing, check that the wire harnesses are not twisted or kinked.



- Wire harnesses routed along with handlebar should not be pulled tight, have excessive slack or interfere with adjacent or surrounding parts in all steering positions.



- When a testing device is used, make sure to understand the operating methods thoroughly and operate according to the operating instructions.



- Be careful not to drop any parts.



- When rust is found on a terminal, remove the rust with sand paper or equivalent before connecting.



- Do not bend or twist control cables. Damaged control cables will not operate smoothly and may stick or bind.

1. GENERAL INFORMATION

■ Symbols:

The following symbols represent the servicing methods and cautions included in this service manual.



Engine Oil

: Apply engine oil to the specified points. (Use designated engine oil for lubrication.)



Grease

: Apply grease for lubrication.



Gear Oil

: Transmission Gear Oil (90#)



Special

: Use special tool.



: Caution



: Warning

(⇒12-3)

: Refer to page 12-3.

1. GENERAL INFORMATION

TORQUE VALUES

STANDARD TORQUE VALUES

Item	Torque (kg-m)	Item	Torque (kg-m)
5mm bolt, nut	0.5	5mm screw	0.4
6mm bolt, nut	1.0	6mm screw, SH bolt	0.9
8mm bolt, nut	2.2	6mm flange bolt, nut	1.2
10mm bolt, nut	3.5	8mm flange bolt, nut	2.7
12mm bolt, nut	5.5	10mm flange bolt, nut	4.0

Torque specifications listed below are for important fasteners.

ENGINE

Item	Q'ty	Thread dia.(mm)	Torque (kg-m)	Remarks
Cylinder head bolt A	2	8	0.9	Double end bolt
Cylinder head bolt B	4	8	0.9	
Oil filter screen cap	1	30	1.5	Double end bolt
Exhaust muffler joint lock nut	2	6	1.2	
Cylinder head nut	4	8	2.0	Apply oil to threads
Valve adjusting lock nut	2	5	0.9	
Cam chain tensioner slipper bolt	1	6	1.0	
Oil bolt	1	8	1.3	
Clutch outer nut	1	12	5.5	
Clutch drive plate nut	1	12	5.5	
Drive face seal cover bolt	3	4	0.3	
Starter clutch cap bolt	3	6	1.2	
Drive face nut	1	12	5.5	Left hand threads
Spark plug	1	10	1.2	
Starter clutch lock nut	1	22	9.5	
Cam chain tensioner screw	1	6	0.4	

FRAME

Item	Q'ty	Thread dia.(mm)	Torque (kg-m)	Remarks
Steering stem lock nut	1	10	12.0	U-nut
Front axle nut	1	12	6.0	U-nut
Rear axle nut	1	14	11.0	U-nut
Rear shock absorber upper mount bolt	1	10	4.0	
Rear shock absorber lower mount bolt	1	8	2.5	
Speedometer cable set screw	1	5	0.45	
Front shock absorber tube bolt	1	5	0.45	
Front shock absorber upper mount bolt	2	8	0.1	
Front shock absorber lower mount bolt	2	8	1.8	
Front shock absorber hex bolt	1	8	3.0	Apply locking agent
Rear shock absorber lower joint lock nut	1	8	3.5	

1. GENERAL INFORMATION

SPECIAL TOOLS

Tool Name	Tool No.	Remarks	Ref. Page
Valve adjuster Valve guide driver Valve guide reamer Valve spring compressor Lock nut wrench, 39mm Bearing driver Bearing driver Bearing remover, 12mm Remover set, 12mm Remover head, 12mm Remover shaft Remover weight Bearing remover set, 15mm Driver set, 15mm Driver shaft, 15mm Driver head, 15mm Driver weight Bearing driver Driver handle Driver weight Clutch spring compressor Outer extension Crankshaft assembly tool Crankshaft assembly collar Crankshaft assembly shaft Attachment Lock nut wrench Lock nut wrench Ball race remover extension Ball race remover Spring compressor Spring compressor attachment Spring compressor attachment Spring compressor attachment Lock nut wrench Driver outer extension Float level gauge Valve spring compressor Valve seat cutter, 24.5mm Valve seat cutter, 25mm Valve seat cutter, 22mm Valve seat cutter, 26mm Cutter clip, 5mm Universal holder Outer driver, 32x35mm Outer driver, 37x40mm Outer driver, 42x47mm Pilot, 12mm Pilot, 15mm Pilot, 17mm Pilot, 20mm Driver handle A Bearing remover shaft Bearing remover head, 12mm Flywheel puller		45° IN/EX Plane cutter 32° IN Plane cutter 32° EX Plane cutter 60° IN/EX	

1. GENERAL INFORMATION

LUBRICATION POINTS

ENGINE

Lubrication Points	Lubricant
Valve guide/valve stem movable part Cam lobes Valve rocker arm friction surface Cam chain Cylinder lock bolt and nut Piston surroundings and piston ring grooves Piston pin surroundings Cylinder inside wall Connecting rod/piston pin hole Connecting rod big end Crankshaft right side oil seal Crankshaft one-way clutch movable part Oil pump drive chain Starter reduction gear engaging part Countershaft gear engaging part Final gear engaging part Bearing movable part O-ring face Oil seal lip	•Genuine KYMCO Engine Oil (SAE10W-30) •API SE, SF or SG Engine Oil
Starter idle gear Friction spring movable part/shaft movable part Shaft movable grooved part Starter spindle movable part	High-temperature resistant grease
Starter one-way clutch threads	Thread locking agent
A.C. generator connector Transmission case breather tube	Adhesive


1. GENERAL INFORMATION

FRAME

The following is the lubrication points for the frame.


Use general purpose grease for parts not listed.

Apply clean engine oil or grease to cables and movable parts not specified. This will avoid abnormal noise and rise the durability of the motorcycle.




1. GENERAL INFORMATION



CABLE & HARNESS ROUTING




1. GENERAL INFORMATION





1. GENERAL INFORMATION



1. GENERAL INFORMATION




1. GENERAL INFORMATION



1. GENERAL INFORMATION

WIRING DIAGRAM


R	Red	O	Orange
B	Black	P	Pink
W	White	Br	Brown
G	Green	LG	Light green
V	Violet	SB	Light blue
L	Blue	GR	Gray
Y	Yellow		



1. GENERAL INFORMATION


TROUBLESHOOTING

ENGINE WILL NOT START OR IS HARD TO START




1. GENERAL INFORMATION

ENGINE LACKS POWER




1. GENERAL INFORMATION

POOR PERFORMANCE (ESPECIALLY AT IDLE AND LOW SPEEDS)



1. GENERAL INFORMATION


POOR PERFORMANCE (AT HIGH SPEED)




1. GENERAL INFORMATION

POOR CHARGING (BATTERY OVER DISCHARGING OR OVERCHARGING)

Undercharging



Overcharging



1. GENERAL INFORMATION

NO SPARK AT SPARK PLUG

