

INTERVAL: THIS INTERVAL SHOULD BE JUDGED BY ODOMETER READING OR MONTHS, WHICHEVER COMES FIRST	miles	600	4 000	7 500	11 000	15 000
	km	1 000	6 000	12 000	18 000	24 000
	months	2	12	24	36	48
Battery (Specific gravity of electrolyte)	-	I	I	I	I	I
*Cylinder head nut & exhaust pipe bolt	T	T	T	T	T	T
Air cleaner element	-	C	C	C	C	C
*Tappet clearance	I	I	I	I	I	I
Spark plug	-	C	R	C	R	R
*Fuel line	I	I	I	I	I	I
Engine oil and oil filter	R	R	R	R	R	R
Carburetor idle rpm	I	I	I	I	I	I
Clutch	I	I	I	I	I	I
Drive shaft gear oil	Change oil at initial 600 miles (1 000 km) and thereafter every 7 500 miles (12 000 km).					
*Brake hoses	I	I	I	I	I	I
*Brake fluid	Replace every four years					
*Brake	Change every two years					
Tires	I	I	I	I	I	I
*Steering stem	I	I	I	I	I	I
*Chassis bolts and nut	T	T	T	T	T	T
Front fork	-	-	I	-	-	-
Check air pressure every 6 months						

NOTE: T = Tighten, C = Clean, I = Inspect, R = Replace