

## HEADLIGHT BEAM ADJUSTMENT



The headlight beam can be adjusted both horizontally and vertically if necessary.

### To adjust the beam horizontally:

Turn the cross head screw (1) located on the left side of the headlight unit clockwise or counter-clockwise.

### To adjust the beam vertically:

Loosen the headlight housing fitting bolt (2) and move the headlight housing up or down as required.

## TURN SIGNAL LIGHT



- (1) Remove two screws and take off the lens.
- (2) Push in on the bulb, twisting it to the left, and pull it out.
- (3) To fit the replacement bulb, push it in and twist it to the right while pushing.

### CAUTION:

After setting the lens, be careful not to overtighten the two securing screws lest the lens should break.

## TAILBRAKE LIGHT



To replace the tail/brake light bulb, follow these directions:

- (1) Remove the two screws and take off the lens.
- (2) Push the bulb in, twisting it to the left until the engagement pins are disconnected and remove the bulb. To fit the replacement bulb into position, push the bulb in firmly and twist it to the right while pushing in.

### CAUTION:

When replacing the lens, do not overtighten the two securing screws.

## FUSE



The fuse box is located inside the left hand frame cover. If the engine suddenly stops, then the fuse must be checked. In case the fuse blows there is one spare fuse, a 15A fuse.

### CAUTION:

Always be sure to replace the blown fuse with the correct amperage fuse. Never use a substitute, for example aluminum foil or wire, to replace a blown fuse. If the spare fuse installed blows in a short period of time it could mean that you have a major electrical problem. You should consult your Suzuki dealer immediately.