

# SERVICING INFORMATION

## CONTENTS

<b>TROUBLESHOOTING .....</b>	<b>8- 2</b>
<b>ENGINE.....</b>	<b>8- 2</b>
<b>RADIATOR.....</b>	<b>8- 5</b>
<b>CARBURETOR .....</b>	<b>8- 5</b>
<b>CHASSIS .....</b>	<b>8- 6</b>
<b>BRAKES.....</b>	<b>8- 7</b>
<b>ELECTRICAL .....</b>	<b>8- 8</b>
<b>BATTERY .....</b>	<b>8- 9</b>
<b>WIRING DIAGRAM.....</b>	<b>8-10</b>
<b>WIRE HARNESS, CABLE AND HOSE ROUTING.....</b>	<b>8-13</b>
<b>WIRE HARNESS ROUTING .....</b>	<b>8-13</b>
<b>WIRING HARNESS ROUTING .....</b>	<b>8-14</b>
<b>SPEED SENSOR LEAD WIRE ROUTING .....</b>	<b>8-15</b>
<b>CABLE ROUTING .....</b>	<b>8-16</b>
<b>FUEL SYSTEM HOSE ROUTING.....</b>	<b>8-17</b>
<b>COOLING SYSTEM HOSE ROUTING.....</b>	<b>8-19</b>
<b>FRONT BRAKE HOSE ROUTING.....</b>	<b>8-20</b>
<b>REAR BRAKE HOSE ROUTING.....</b>	<b>8-21</b>
<b>PAIR (AIR SUPPLY) SYSTEM HOSE ROUTING .....</b>	<b>8-22</b>
<b>FUEL TANK SET-UP.....</b>	<b>8-23</b>
<b>SPECIAL TOOLS .....</b>	<b>8-24</b>
<b>TIGHTENING TORQUE.....</b>	<b>8-27</b>
<b>ENGINE.....</b>	<b>8-27</b>
<b>CHASSIS .....</b>	<b>8-28</b>
<b>TIGHTENING TORQUE CHART .....</b>	<b>8-30</b>
<b>SERVICE DATA .....</b>	<b>8-31</b>

## TROUBLESHOOTING

### ENGINE

Complaint	Symptom and possible causes	Remedy
<b>Engine will not start, or is hard to start.</b>	<p><b>Compression too low</b></p> <ol style="list-style-type: none"> <li>1. Out of adjustment tappet clearance.</li> <li>2. Worn valve guides or poor seating of valves.</li> <li>3. Mistiming valves.</li> <li>4. Excessively worn piston rings.</li> <li>5. Worn-down cylinder bore.</li> <li>6. Too slowly starter motor cranks.</li> <li>7. Poor seating of spark plug.</li> </ol> <p><b>Plugs not sparking</b></p> <ol style="list-style-type: none"> <li>1. Fouled spark plug.</li> <li>2. Wet spark plug.</li> <li>3. Defective ignition coil.</li> <li>4. Open or short in high-tension cord.</li> <li>5. Defective signal generator or ignitor unit.</li> </ol> <p><b>No fuel reaching the carburetors</b></p> <ol style="list-style-type: none"> <li>1. Clogged fuel tank air breather hose.</li> <li>2. Clogged or defective vacuum fuel valve.</li> <li>3. Defective fuel pump.</li> <li>4. Defective carburetor needle valve.</li> <li>5. Clogged fuel hose or fuel filter.</li> </ol>	<p>Adjust. Repair or replace. Adjust. Replace. Replace or rebore. See electrical section. Retighten.</p> <p>Clean. Clean and dry. Replace. Replace. Replace.</p> <p>Clean or replace. Clean or replace. Replace. Replace. Clean or replace.</p>
<b>Engine stalls easily.</b>	<ol style="list-style-type: none"> <li>1. Fouled spark plugs.</li> <li>2. Defective signal generator or ignitor unit.</li> <li>3. Clogged fuel hose.</li> <li>4. Clogged jets in carburetor.</li> <li>5. Out of adjustment tappet clearance.</li> </ol>	<p>Clean. Replace. Clean. Clean. Adjust.</p>
<b>Noisy engine.</b>	<p><b>Excessive valve chatter</b></p> <ol style="list-style-type: none"> <li>1. Too large valve clearance.</li> <li>2. Weakened or broken valve springs.</li> <li>3. Worn tappet or cam surface.</li> <li>4. Worn and burnt camshaft journal.</li> </ol> <p><b>Noise seems to come from piston</b></p> <ol style="list-style-type: none"> <li>1. Worn down piston or cylinders.</li> <li>2. Fouled with carbon combustion chambers.</li> <li>3. Worn piston pins or piston pin bore.</li> <li>4. Worn piston rings or ring grooves.</li> </ol> <p><b>Noise seems to come from timing chain</b></p> <ol style="list-style-type: none"> <li>1. Stretched chain.</li> <li>2. Worn sprockets.</li> <li>3. Not working tension adjuster.</li> </ol> <p><b>Noise seems to come from clutch</b></p> <ol style="list-style-type: none"> <li>1. Worn splines of countershaft or hub.</li> <li>2. Worn teeth of clutch plates.</li> <li>3. Distorted clutch plates, driven and drive.</li> <li>4. Worn clutch release bearing.</li> <li>5. Weakened clutch dampers.</li> </ol>	<p>Adjust. Replace. Replace. Replace.</p> <p>Replace. Clean. Replace. Replace.</p> <p>Replace. Replace. Repair or replace.</p> <p>Replace. Replace. Replace. Replace. Replace the primary driven gear.</p>

Complaint	Symptom and possible causes	Remedy
<b>Noisy engine.</b>	<p><b>Noise seems to come from crankshaft</b></p> <ol style="list-style-type: none"> <li>1. Due to wear rattling bearings.</li> <li>2. Worn and burnt big-end bearings.</li> <li>3. Worn and burnt journal bearings.</li> <li>4. Too large thrust clearance.</li> </ol> <p><b>Noise seems to come from transmission</b></p> <ol style="list-style-type: none"> <li>1. Worn or rubbing gears.</li> <li>2. Badly worn splines.</li> <li>3. Worn or rubbing primary gears.</li> <li>4. Badly worn bearings.</li> </ol> <p><b>Noise seems to come from water pump</b></p> <ol style="list-style-type: none"> <li>1. Too much play on pump shaft bearing.</li> <li>2. Worn or damaged mechanical seal.</li> <li>3. Touches pump case and impeller.</li> </ol>	<p>Replace. Replace. Replace. Replace thrust bearing.</p> <p>Replace. Replace. Replace. Replace.</p> <p>Replace. Replace. Replace.</p>
<b>Slipping clutch.</b>	<ol style="list-style-type: none"> <li>1. Out of adjustment or loss of play clutch control.</li> <li>2. Weakened clutch springs.</li> <li>3. Worn or distorted pressure plate.</li> <li>4. Distorted clutch plates, driven and drive.</li> </ol>	<p>Adjust. Replace. Replace. Replace.</p>
<b>Dragging clutch.</b>	<ol style="list-style-type: none"> <li>1. Out of adjustment or loss of play clutch control.</li> <li>2. Clutch springs weakened.</li> <li>3. Distorted pressure plate or clutch plate.</li> </ol>	<p>Adjust. Replace. Replace.</p>
<b>Transmission will not shift.</b>	<ol style="list-style-type: none"> <li>1. Broken gearshift cam.</li> <li>2. Distorted gearshift forks.</li> <li>3. Worn gearshift cam plate.</li> </ol>	<p>Replace. Replace. Replace.</p>
<b>Transmission will not shift back.</b>	<ol style="list-style-type: none"> <li>1. Broken return spring on shift shaft.</li> <li>2. Rubbing or sticky shift shaft.</li> <li>3. Distorted or worn gearshift forks.</li> </ol>	<p>Replace. Repair or replace. Replace.</p>
<b>Transmission jumps out of gear.</b>	<ol style="list-style-type: none"> <li>1. Worn shifting gears on driveshaft or countershaft.</li> <li>2. Distorted or worn gearshift forks.</li> <li>3. Weakened stopper spring on gearshift stopper.</li> <li>4. Worn gearshift cam plate.</li> </ol>	<p>Replace. Replace. Replace. Replace.</p>
<b>Engine idles poorly.</b>	<ol style="list-style-type: none"> <li>1. Out of adjustment tappet clearance.</li> <li>2. Poor seating of valves.</li> <li>3. Defective valve guides.</li> <li>4. Worn tappet or cam surface.</li> <li>5. Too wide spark plug gaps.</li> <li>6. Defective ignition coil.</li> <li>7. Defective signal generator or ignitor unit.</li> <li>8. Out of adjustment in carburetor float-chamber fuel level.</li> <li>9. Clogged jets or imbalance of carburetors.</li> <li>10. Defective fuel pump.</li> </ol>	<p>Adjust. Replace or repair. Replace. Replace. Adjust or replace. Replace. Replace. Adjust. Clean or adjust. Replace</p>

Complaint	Symptom and possible causes	Remedy
<b>Engine runs poorly in high speed range.</b>	<ol style="list-style-type: none"> <li>1. Weakened valve springs.</li> <li>2. Worn camshafts.</li> <li>3. Valve timing out of adjustment.</li> <li>4. Too narrow spark plug gaps.</li> <li>5. Ignition not advanced sufficiently due to poorly working timing advance circuit.</li> <li>6. Defective ignition coil.</li> <li>7. Defective signal generator or ignitor unit.</li> <li>8. Too low float-chamber fuel level.</li> <li>9. Clogged air cleaner element.</li> <li>10. Clogged fuel hose, resulting in inadequate fuel supply to carburetors.</li> <li>11. Defective fuel pump.</li> </ol>	<p>Replace. Replace. Adjust. Adjust. Replace ignitor unit.</p> <p>Replace. Replace. Adjust. Clean. Clean and prime.</p> <p>Replace.</p>
<b>Dirty or heavy exhaust smoke.</b>	<ol style="list-style-type: none"> <li>1. Too much engine oil in the engine.</li> <li>2. Worn piston rings or cylinders.</li> <li>3. Worn valve guides.</li> <li>4. Scored or scuffed cylinder walls.</li> <li>5. Worn valves or stems.</li> <li>6. Defective stem seal.</li> <li>7. Worn oil ring side rails.</li> </ol>	<p>Check with inspection window drain out excess oil.</p> <p>Replace. Replace. Rebore. Replace. Replace. Replace.</p>
<b>Engine lacks power.</b>	<ol style="list-style-type: none"> <li>1. Loss of tappet clearance.</li> <li>2. Weakened valve springs.</li> <li>3. Out of adjustment valve timing.</li> <li>4. Worn piston rings or cylinders.</li> <li>5. Poor seating of valves.</li> <li>6. Fouled spark plug.</li> <li>7. Incorrect spark plug.</li> <li>8. Clogged jets in carburetors.</li> <li>9. Out of adjustment float-chamber fuel level.</li> <li>10. Clogged air cleaner element.</li> <li>11. Loose carburetor balancing screw..</li> <li>12. Sucking air from intake pipe.</li> <li>13. Too much engine oil.</li> <li>14. Defective fuel pump.</li> </ol>	<p>Adjust. Replace. Adjust. Replace. Repair. Clean or replace. Adjust or replace. Clean. Adjust. Clean. Retighten. Retighten or replace. Drain out excess oil. Replace.</p>
<b>Engine overheats.</b>	<ol style="list-style-type: none"> <li>1. Heavy carbon deposit on piston crowns.</li> <li>2. Not enough oil in the engine.</li> <li>3. Defective oil pump or clogged oil circuit.</li> <li>4. Too low in float chambers fuel level.</li> <li>5. Sucking air from intake pipes.</li> <li>6. Use incorrect engine oil.</li> <li>7. Defective cooling system.</li> </ol>	<p>Clean. Add oil. Replace or clean. Adjust. Retighten or replace. Change. See radiator section.</p>

**RADIATOR**

<b>Complaint</b>	<b>Symptom and possible causes</b>	<b>Remedy</b>
<b>Engine overheats.</b>	<ol style="list-style-type: none"> <li>1. Not enough cooling water.</li> <li>2. Clogged with dirt or trades radiator core.</li> <li>3. Erratic thermostat, stuck in closed position.</li> <li>4. Faulty cooling fan.</li> <li>5. Defective thermo-switch.</li> <li>6. Clogged water passage.</li> <li>7. Air trapped in the cooling circuit.</li> <li>8. Defective water pump.</li> <li>9. Use incorrect coolant.</li> </ol>	<p>Add coolant. Clean. Replace. Repair or replace. Replace. Clean. Bleed out air. Replace. Replace.</p>
<b>Engine overcools.</b>	<ol style="list-style-type: none"> <li>1. Erratic thermostat, stuck in full-open position.</li> <li>2. Defective thermo-switch.</li> <li>3. Extremely cold weather.</li> </ol>	<p>Replace. Replace. Put on the radiator cover.</p>

**CARBURETOR**

<b>Complaint</b>	<b>Symptom and possible causes</b>	<b>Remedy</b>
<b>Trouble with starting.</b>	<ol style="list-style-type: none"> <li>1. Clogged starter jet.</li> <li>2. Clogged starter pipe.</li> <li>3. Air leaking from a joint between starter body and carburetor.</li> <li>4. Air leaking from carburetor's joint or vacuum hose joint.</li> <li>5. Not operation properly starter plunger.</li> </ol>	<p>Clean. Clean. Check starter body and carburetor for tightness, adjust and replace gasket. Check and adjust. Check and adjust.</p>
<b>Idling or low-speed trouble.</b>	<ol style="list-style-type: none"> <li>1. Clogged or loose pilot jet, pilot air jet.</li> <li>2. Air leaking from carburetor's joint, vacuum hose joint, or starter.</li> <li>3. Clogged pilot outlet or bypass.</li> <li>4. Not fully closed starter plunger.</li> </ol>	<p>Check and clean. Check and adjust. Check and clean. Check and adjust.</p>
<b>Medium-or high speed trouble.</b>	<ol style="list-style-type: none"> <li>1. Clogged main jet or main air jet.</li> <li>2. Clogged needle jet.</li> <li>3. Not operating properly throttle valve.</li> <li>4. Clogged fuel filter.</li> </ol>	<p>Check and clean. Check and clean. Check throttle valve for operation. Check and clean.</p>
<b>Overflow and fuel level fluctuations.</b>	<ol style="list-style-type: none"> <li>1. Worn or damaged needle valve.</li> <li>2. Broken spring in needle valve.</li> <li>3. Not working properly float.</li> <li>4. Foreign matter has adhered to needle valve.</li> <li>5. Too high or low fuel level.</li> <li>6. Defective fuel pump.</li> </ol>	<p>Replace. Replace. Check and adjust. Clean. Adjust float height. Replace.</p>

**CHASSIS**

<b>Complaint</b>	<b>Symptom and possible causes</b>	<b>Remedy</b>
<b>Heavy steering.</b>	<ol style="list-style-type: none"> <li>1. Overtightened steering stem nut.</li> <li>2. Broken bearing in steering stem.</li> <li>3. Distorted steering stem.</li> <li>4. Not enough pressure in tires.</li> </ol>	Adjust. Replace. Replace. Adjust.
<b>Wobbly handlebars.</b>	<ol style="list-style-type: none"> <li>1. Loss of balance between right and left front forks.</li> <li>2. Distorted front fork.</li> <li>3. Distorted front axle or crooked tire.</li> <li>4. Worn bearing/race in steering stem.</li> </ol>	Replace. Repair or replace. Replace. Replace.
<b>Wobby front wheel.</b>	<ol style="list-style-type: none"> <li>1. Distorted wheel rim.</li> <li>2. Worn front wheel bearing.</li> <li>3. Defective or incorrect tire.</li> <li>4. Loose axle, axle nut or axle pinch bolts.</li> <li>5. Incorrect front fork oil level.</li> </ol>	Replace. Replace. Replace. Retighten. Adjust.
<b>Front suspension too soft.</b>	<ol style="list-style-type: none"> <li>1. Weakened springs.</li> <li>2. Not enough fork oil.</li> <li>3. Wrong weight tank oil.</li> </ol>	Replace. Replenish. Replace.
<b>Front suspension too stiff.</b>	<ol style="list-style-type: none"> <li>1. Too viscous fork oil.</li> <li>2. Too much fork oil.</li> <li>3. Bent front axle.</li> </ol>	Replace. Drain excess oil. Replace.
<b>Noisy front suspension.</b>	<ol style="list-style-type: none"> <li>1. Not enough fork oil.</li> <li>2. Loose bolts on suspension.</li> </ol>	Replenish. Retighten.
<b>Wobbly rear wheel.</b>	<ol style="list-style-type: none"> <li>1. Distorted wheel rim.</li> <li>2. Worn rear wheel bearing or swingarm bearings.</li> <li>3. Defective or incorrect tire.</li> <li>4. Worn swingarm and rear cushion related bearings.</li> <li>5. Loose nuts or bolts on rear suspensions.</li> </ol>	Replace. Replace. Replace. Replace. Retighten.
<b>Rear suspension too soft.</b>	<ol style="list-style-type: none"> <li>1. Weakened shock absorber spring.</li> <li>2. Improperly set rear suspension adjuster.</li> <li>3. Leakage oil of shock absorber.</li> <li>4. Leakage gas of shock absorber.</li> </ol>	Replace. Adjust. Replace. Replace.
<b>Rear suspension too stiff.</b>	<ol style="list-style-type: none"> <li>1. Improperly set rear suspension adjuster.</li> <li>2. Bent shock absorber shaft.</li> <li>3. Bent swingarm.</li> <li>4. Worn swingarm and rear cushion related bearings.</li> </ol>	Adjust. Replace. Replace. Replace.
<b>Noisy rear suspension.</b>	<ol style="list-style-type: none"> <li>1. Loose nuts or bolts on rear suspension.</li> <li>2. Worn swingarm and rear cushion related bearings.</li> </ol>	Retighten. Replace.

**BRAKES**

<b>Complaint</b>	<b>Symptom and possible causes</b>	<b>Remedy</b>
<b>Insufficient brake power.</b>	<ol style="list-style-type: none"> <li>1. Leakage of brake fluid from hydraulic system.</li> <li>2. Worn pads.</li> <li>3. Oil adhesion of engaging surface of pads.</li> <li>4. Worn disc.</li> <li>5. Air in hydraulic system.</li> </ol>	<p>Repair or replace.            Replace.            Clean disc and pads.            Replace.            Bleed air.</p>
<b>Brake squeaking.</b>	<ol style="list-style-type: none"> <li>1. Carbon adhesion on pad surface.</li> <li>2. Tilted pad.</li> <li>3. Damaged wheel bearing.</li> <li>4. Loosen front-wheel axle or rear-wheel axle.</li> <li>5. Worn pads.</li> <li>6. Foreign material in brake fluid.</li> <li>7. Clogged return port of master cylinder.</li> </ol>	<p>Repair surface with sandpaper.            Modify pad fitting or replace.            Replace.            Tighten to specified torque.            Replace.            Replace brake fluid.            Disassemble and clean master cylinder.</p>
<b>Excessive brake lever stroke.</b>	<ol style="list-style-type: none"> <li>1. Air in hydraulic system.</li> <li>2. Insufficient brake fluid.</li> <li>3. Improper quality of brake fluid.</li> </ol>	<p>Bleed air.            Replenish fluid to specified level; bleed air.            Replace with correct fluid.</p>
<b>Leakage of brake fluid</b>	<ol style="list-style-type: none"> <li>1. Insufficient tightening of connection joints.</li> <li>2. Cracked hose.</li> <li>3. Worn piston and/or cup.</li> </ol>	<p>Tighten to specified torque.            Replace.            Replace piston and/or cup.</p>
<b>Brake drags.</b>	<ol style="list-style-type: none"> <li>1. Rusty part.</li> <li>2. Insufficient brake lever or brake pedal pivot lubrication.</li> </ol>	<p>Clean and lubricate.            Lubricate.</p>


**ELECTRICAL**

<b>Complaint</b>	<b>Symptom and possible causes</b>	<b>Remedy</b>
<b>No sparking or poor sparking.</b>	<ol style="list-style-type: none"> <li>1. Defective ignition coil.</li> <li>2. Defective spark plugs.</li> <li>3. Defective signal generator or ignitor unit.</li> </ol>	<p>Replace. Replace. Replace.</p>
<b>Spark plug soon become fouled with carbon.</b>	<ol style="list-style-type: none"> <li>1. Mixture too rich.</li> <li>2. Idling speed set too high.</li> <li>3. Incorrect gasoline.</li> <li>4. Dirty element in air cleaner.</li> <li>5. Too cold spark plug.</li> </ol>	<p>Adjust carburetors. Adjust carburetors. Change. Clean. Replace with hot type plugs.</p>
<b>Spark plugs become fouled too soon.</b>	<ol style="list-style-type: none"> <li>1. Worn piston rings.</li> <li>2. Worn piston or cylinders.</li> <li>3. Excessive clearance of valve stem in valve guides.</li> <li>4. Worn stem oil seal.</li> </ol>	<p>Replace. Replace. Replace.  Replace.</p>
<b>Spark plug electrodes overheat or burn.</b>	<ol style="list-style-type: none"> <li>1. Too hot spark plugs.</li> <li>2. Overheated the engine.</li> <li>3. Loose spark plugs.</li> <li>4. Too lean mixture.</li> </ol>	<p>Replace with cold type plugs. Tune up. Retighten. Adjust carburetors.</p>
<b>Generator does not charge.</b>	<ol style="list-style-type: none"> <li>1. Open or short lead wires, or loose lead connections.</li> <li>2. Shorted, grounded or open generator coils.</li> <li>3. Shorted or punctured regulator/rectifiers.</li> </ol>	<p>Repair or replace or retighten. Replace. Replace.</p>
<b>Generator does charge, but charging rate is below the specification.</b>	<ol style="list-style-type: none"> <li>1. Lead wires tend to get shorted or open-circuited or loosely connected at terminals.</li> <li>2. Grounded or open-circuited stator coils or generator.</li> <li>3. Defective regulator/rectifier.</li> <li>4. Defective cell plates in the battery.</li> </ol>	<p>Repair or retighten.  Replace.  Replace. Replace the battery.</p>
<b>Generator overcharges.</b>	<ol style="list-style-type: none"> <li>1. Internal short-circuit in the battery.</li> <li>2. Damaged or defective resistor element in the regulator/rectifier.</li> <li>3. Poorly grounded regulator/rectifier.</li> </ol>	<p>Replace the battery. Replace.  Clean and tighten ground connection.</p>
<b>Unstable charging.</b>	<ol style="list-style-type: none"> <li>1. Lead wire insulation frayed due to vibration, resulting in intermittent shorting.</li> <li>2. Internally shorted generator.</li> <li>3. Defective regulator/rectifier.</li> </ol>	<p>Repair or replace.  Replace. Replace.</p>
<b>Starter button is not effective.</b>	<ol style="list-style-type: none"> <li>1. Run down battery.</li> <li>2. Defective switch contacts.</li> <li>3. Not seating properly brushes on commutator in starter motor.</li> <li>4. Defective starter relay/starter interlock switch.</li> </ol>	<p>Repair or replace. Replace. Repair or replace.  Replace.</p>


**BATTERY**

<b>Complaint</b>	<b>Symptom and possible causes</b>	<b>Remedy</b>
<b>“Sulfation”, acidic white powdery substance or spots on surface of cell plates.</b>	<ol style="list-style-type: none"> <li>1. Cracked battery case.</li> <li>2. Battery has been left in a run-down condition for a long time.</li> </ol>	<p>Replace the battery.</p> <p>Replace the battery.</p>
<b>Battery runs down quickly.</b>	<ol style="list-style-type: none"> <li>1. Not correct the charging system.</li> <li>2. Cell plates have lost much of their active material as a result of overcharging.</li> <li>3. A short-circuit condition exists within the battery.</li> <li>4. Too low battery voltage.</li> <li>5. Too old battery.</li> </ol>	<p>Check the generator, regulator/rectifier and circuit connections and make necessary adjustments to obtain specified charging operation.</p> <p>Replace the battery, and correct the charging system.</p> <p>Replace the battery.</p> <p>Recharge the battery fully.</p> <p>Replace the battery.</p>
<b>Battery “sulfation”.</b>	<ol style="list-style-type: none"> <li>1. Too low or too high charging rate. (When not in use batteries should be checked at least once a month to avoid sulfation.)</li> <li>2. Left unused the battery for too long in cold climate.</li> </ol>	<p>Replace the battery.</p> <p>Replace the battery, if badly sulfated.</p>
<b>Battery discharges too rapidly.</b>	Dirty container top and sides.	Clean.

# WIRING DIAGRAM (FOR U.S.A. AND CANADA MODELS)



(FOR E-24 MODEL)




- O : OIL PRESSURE INDICATOR LIGHT
- F : FUEL LEVEL INDICATOR LIGHT
- H : HEAD BEAM INDICATOR LIGHT
- T : TURN SIGNAL INDICATOR LIGHT
- N : NEUTRAL INDICATOR LIGHT
- WT : ENGINE COOLANT TEMP. INDICATOR

WIRE COLORS

- B ..... Black
- Bl ..... Blue
- Br ..... Brown
- G ..... Green
- Gr ..... Gray
- Lbl ..... Light blue
- Llg ..... Light green
- O ..... Orange
- P ..... Pink
- R ..... Red
- W ..... White
- Y ..... Yellow
- B/Bl ..... Black with Blue tracer
- B/Br ..... Black with Brown tracer
- B/G ..... Black with Green tracer
- Bl/G ..... Black with Light green tracer
- Bl/R ..... Black with Red tracer
- Bl/Y ..... Black with Yellow tracer
- B/W ..... Blue with White tracer
- G/Bl ..... Green with Blue tracer
- G/Y ..... Green with Yellow tracer
- O/B ..... Orange with Black tracer
- O/Bl ..... Orange with Blue tracer
- O/G ..... Orange with Green tracer
- O/R ..... Orange with Red tracer
- O/W ..... Orange with White tracer
- O/Y ..... Orange with Yellow tracer
- R/W ..... Red with White tracer
- R/Y ..... Red with Yellow tracer
- W/Bl ..... White with Blue tracer
- W/Br ..... White with Brown tracer
- W/B ..... White with Black tracer
- Y/B ..... Yellow with Black tracer
- Y/Bl ..... Yellow with Blue tracer
- Y/Br ..... Yellow with Brown tracer
- Y/W ..... Yellow with White tracer


(FOR E-02, 04, 17, 18, 22, 25 AND 34 MODELS)









# SPEED SENSOR LEAD WIRE ROUTING




# CABLE ROUTING




# FUEL SYSTEM HOSE ROUTING









# FRONT BRAKE HOSE ROUTING




# REAR BRAKE HOSE ROUTING





















# PAIR (AIR SUPPLY) SYSTEM HOSE ROUTING (FOR CALIFORNIA)
















# FUEL TANK SET-UP















## SPECIAL TOOLS

 <p>09900-06104 Snap ring pliers</p>	 <p>09900-06107 Snap ring pliers</p>	 <p>09900-06108 Snap ring pliers</p>	 <p>09900-09004 Impact driver set</p>	 <p>09900-20101 or 09900-20102 Vernier calipers</p>
 <p>09900-20202 Micrometer (25 – 50 mm)</p>	 <p>09900-20204 Micrometer (75 – 100 mm)</p>	 <p>09900-20205 Micrometer (0 – 25 mm)</p>	 <p>09900-20508 Cylinder gauge set</p>	 <p>09900-20602 Dial gauge (1/1000 mm, 1 mm)</p>
 <p>09900-20606 Dial gauge (1/100 mm, 10 mm)</p>	 <p>09900-20701 Magnetic stand</p>	 <p>09900-20803 09900-20806 Thickness gauge</p>	 <p>09900-20805 Tire depth gauge</p>	 <p>09900-21304 V-block (100 mm)</p>
 <p>09900-22301 09900-22302 Plastigauge</p>	 <p>09900-22403 Small bore gauge (18 – 35 mm)</p>	 <p>09900-25008 Multi circuit tester set</p>	 <p>09910-20116 Conrod holder</p>	 <p>09915-63310 Compression gauge adapter</p>
 <p>09913-13121 Carburetor balancer set</p>	 <p>09913-50121 Oil seal remover</p>	 <p>09913-60220 Journal bearing remover/installer</p>	 <p>09913-70210 Bearing installer set</p>	 <p>09915-40610 Oil filter wrench</p>

 <p>09915-64510 Compression gauge</p>	 <p>09915-74520 Oil pressure gauge hose</p>	 <p>09915-74532 Oil pressure gauge adaptor</p>	 <p>09915-77330 Meter (for high pressure)</p>	 <p>09916-10911 Valve lapper set</p>
 <p>09916-14510 Valve spring compressor</p>	 <p>09916-14521 Valve spring compressor attachment</p>	 <p>09916-21111 Valve seat cutter set</p>	 <p>09916-20640 Solid pilot (N-100-4.5)</p>	 <p>09916-20630 Valve seat cutter head (N-126)</p>
 <p>09916-34542 Reamer handle</p>	 <p>09916-33210 Valve guide reamer (4.5 mm)</p>	 <p>09916-34580 Valve guide reamer (10.8 mm)</p>	 <p>09916-43210 Valve guide remover/installer</p>	 <p>09916-53330 Attachment</p>
 <p>09916-84511 Tweezers</p>	 <p>09917-47010 Vacuum pump gauge set</p>	 <p>09917-62430 Cam chain tension adjuster locking tool</p>	 <p>09920-13120 Crankcase separating tool</p>	 <p>09920-53740 Clutch sleeve hub holder</p>
 <p>09921-20220 Bearing remover set</p>	 <p>09923-80210 Oil seal guide</p>	 <p>09924-84510 Bearing installer set</p>	 <p>09924-84521 Bearing installer set</p>	 <p>09930-11920 Torx bit JT40H</p>

8-26 SERVICING INFORMATION

 <p>09930-11940 Bit holder</p>	 <p>09930-30450 Rotor remover</p>	 <p>09930-44530 Rotor holder</p>	 <p>09940-14911 Steering stem nut wrench</p>	 <p>09940-14940 Swingarm adjuster lock nut wrench</p>
 <p>09940-14990 Engine mounting thrust adjuster socket wrench</p>	 <p>09940-34520 T handle</p>	 <p>09940-34531 Attachment A</p>	 <p>09940-52861 Front fork oil seal installer set</p>	 <p>09940-92720 Spring scale</p>
 <p>09941-34513 Bearing/steering race installer set</p>	 <p>09941-50111 Wheel bearing remover</p>	 <p>09941-54911 Bearing outer race remover</p>	 <p>09941-74911 Steering bearing installer</p>	 <p>09943-74111 Fork oil level gauge</p>
 <p>09913-10760 Fuel level gauge</p>				

**NOTE:**

When order the special tool, please confirm whether it is available or not.

**TIGHTENING TORQUE****ENGINE**

ITEM		N-m	kgf-m	lb-ft
Cylinder head cover bolt		14	1.4	10.0
Spark plug		11	1.1	8.0
Camshaft journal holder bolt		10	1.0	7.0
Cam chain tension adjuster bolt		8	0.8	6.0
Cam chain tension adjuster mounting bolt		10	1.0	7.0
Cam chain guide bolt		10	1.0	7.0
Cam chain tensioner mounting bolt		10	1.0	7.0
Cylinder head bolt [M10]	(Initial)	25	2.5	18.0
	(Final)	42	4.2	30.5
Cylinder head bolt [M6]		10	1.0	7.0
Cylinder head side bolt		14	1.4	1.0
Cylinder nut	[M:6]	10	1.0	7.0
Water drain bolt		13	1.3	9.5
Impeller securing bolt		13	1.3	9.5
Clutch sleeve hub nut		50	5.0	36.0
Clutch spring set bolt		5.5	0.55	4.0
Oil plate bolt		10	1.0	7.0
Oil pressure regulator		27	2.7	19.5
Oil strainer plate bolt		10	1.0	7.0
Primary drive gear bolt		70	7.0	50.5
Generator cover plug		11	1.1	8.0
Valve timing inspection plug		23	2.3	16.5
Generator rotor bolt		120	12.0	87.0
Starter clutch bolt		25	2.5	18.0
Generator stator set bolt		10	1.0	7.0
Signal generator set bolt		5.5	0.55	4.0
Gerarshift cam stopper bolt		10	1.0	7.0
Gearshift cam stopper plate bolt		10	1.0	7.0
Gearshift arm stopper bolt		23	2.3	16.5
Oil pressure switch		14	1.4	10.0
Crankcase bolt	[M:6]	11	1.1	8.0
	[M:8]	26	2.6	19.0
Generator cover bolt	[M:6]	10	1.0	7.0
Clutch cover bolt	[M:6]	10	1.0	7.0
Water pump case screw		4.5	0.45	3.3

**8-28 SERVICING INFORMATION**

ITEM		N·m	kgf·m	lb·ft
Oil gallery plug	[M:16]	35	3.5	25.5
	[M:8]	18	1.8	13.0
	[M6]	5.5	0.55	4.0
Oil drain plug		21	2.1	15.0
Piston cooling oil jet bolt		10	1.0	7.0
Oil pump mounting bolt		8	0.8	6.0
Conrod bearing cap bolt	(Initial)	35	3.5	25.5
	(Final)	67	6.7	48.5
Exhaust pipe bolt		23	2.3	16.5
Crankcase bearing retainer screw		8	0.8	6.0
Muffler mounting nut		23	2.3	16.5
Muffler joint nut		23	2.3	16.5
Oil pipe stopper screw		8	0.8	6.0
Engine sprocket nut		145	14.5	105
Engine mounting pinch bolt		23	2.3	16.5
Engine mounting bolt/nut	[M:12]	93	9.3	67.5
	[M:10]	55	5.5	40.0
Engine mounting thrust adjuster	[Center]	10	1.0	7.0
	[Rear Lower]	10	1.0	7.0
Engine mounting thrust adjuster lock nut	[Center]	45	4.5	32.5
	[Rear Lower]	45	4.5	32.5
Cooling fan thermo-switch		13	1.3	9.5
Engine coolant temperature switch		10	1.0	7.0

**CHASSIS**


ITEM	N·m	kgf·m	lb·ft
Steering stem head nut	65	6.5	47.0
Front fork upper clamp bolt	23	2.3	16.5
Front fork lower clamp bolt	23	2.3	16.5
Front fork cap bolt	23	2.3	16.5
Front fork damper rod bolt	30	3.0	21.5
Front axle	65	6.5	47.0
Front axle pinch bolt	23	2.3	16.5
Handlebar clamp bolt	23	2.3	16.5
Handlebar holder nut	45	4.5	32.5

ITEM	N-m	kgf-m	lb-ft
Front brake master cylinder mounting bolt	10	1.0	7.0
Front brake caliper mounting bolt	39	3.9	28.0
Brake hose union bolt	23	2.3	16.5
Clutch holder mounting bolt	10	1.0	7.0
Air bleeder valve	7.5	0.75	5.5
Brake disc bolt (Front and Rear)	23	2.3	16.5
Rear brake caliper mounting bolt	26	2.6	19.0
Rear brake caliper housing bolt	30	3.0	21.5
Rear brake master cylinder mounting bolt	10	1.0	7.0
Rear brake master cylinder rod lock nut	18	1.8	13.0
Front footrest bracket mounting bolt	23	2.3	16.5
Front footrest bolt	39	3.9	28.0
Swingarm pivot shaft	15	1.5	11.0
Swingarm pivot shaft nut	100	10.0	72.5
Swingarm pivot shaft lock nut	90	9.0	65.0
Torque link nut (Front and Rear)	35	3.5	25.5
Rear shock absorber mounting bolt/nut (Upper & Lower)	50	5.0	36.0
Rear cushion lever/rod mounting nut	78	7.8	56.5
Rear axle nut	65	6.5	47.0
Rear sprocket nut	60	6.0	43.5


### TIGHTENING TORQUE CHART

For other bolts and nuts listed previously, refer to this chart:


Bolt Diameter Ⓐ (mm)	Conventional or "4" marked bolt			"7" marked bolt		
	N·m	kgf·m	lb-ft	N·m	kgf·m	lb-ft
4	1.5	0.15	1.0	2.3	0.23	1.5
5	3	0.3	2.0	4.5	0.45	3.0
6	5.5	0.55	4.0	10	1.0	7.0
8	13	1.3	9.5	23	2.3	16.5
10	29	2.9	21.0	50	5.0	36.0
12	45	4.5	32.5	85	8.5	61.5
14	65	6.5	47.0	135	13.5	97.5
16	105	10.5	76.0	210	21.0	152.0
18	160	16.0	115.5	240	24.0	173.5



Conventional bolt



"4" marked bolt



"7" marked bolt

**SERVICE DATA****VALVE + GUIDE**

Unit: mm (in)

ITEM		STD/SPEC.	LIMIT
Valve diam.	IN.	31 (1.2)	——
	EX.	25.5 (1.0)	——
Valve clearance (When cold)	IN.	0.1 – 0.2 (0.004 – 0.008)	——
	EX.	0.2 – 0.3 (0.008 – 0.012)	——
Valve guide to valve stem clearance	IN.	0.020 – 0.047 (0.0008 – 0.0019)	——
	EX.	0.030 – 0.057 (0.0012 – 0.0022)	——
Valve guide I.D.	IN. & EX.	4.500 – 4.512 (0.1772 – 0.1776)	——
Valve stem O.D.	IN.	4.465 – 4.480 (0.1758 – 0.1764)	——
	EX.	4.455 – 4.470 (0.1754 – 0.1760)	——
Valve stem deflection	IN. & EX.	——	0.35 (0.014)
Valve stem runout	IN. & EX.	——	0.05 (0.002)
Valve head thickness	IN. & EX.	——	0.5 (0.02)
Valve seat width	IN. & EX.	0.9 – 1.1 (0.035 – 0.043)	——
Valve head radial runout	IN. & EX.	——	0.03 (0.001)
Valve spring free length (IN. & EX.)	INNER	——	36.8 (1.45)
	OUTER	——	39.8 (1.57)
Valve spring tension (IN. & EX.)	INNER	4.2 – 4.8 kgf (9.26 – 10.58 lbs) at length 29.9 mm (1.18 in)	——
	OUTER	17.0 – 19.6 kg (37.48 – 43.21 lbs) at length 33.4 mm (1.31 in)	——

**CAMSHAFT + CYLINDER HEAD**

Unit: mm (in)

ITEM		STD/SPEC.	LIMIT
Cam height	IN.	35.480 – 35.530 (1.397 – 1.399)	35.18 (1.385)
	EX.	33.480 – 33.530 (1.318 – 1.320)	33.18 (1.306)
Camshaft journal oil clearance	IN. & EX.	0.032 – 0.066 (0.0013 – 0.0026)	0.150 (0.0059)
Camshaft journal holder I.D.	IN. & EX.	22.012 – 22.025 (0.8666 – 0.8671)	—
Camshaft journal O.D.	IN. & EX.	21.959 – 21.980 (0.8645 – 0.8654)	—
Camshaft runout	IN. & EX.	—	0.10 (0.004)
Cam chain pin (at arrow "3")		16th pin	—
Cylinder head distortion		—	0.05 (0.002)

**CONROD + CRANKSHAFT**

Unit: mm (in)

ITEM	STD/SPEC.	LIMIT
Conrod small end I.D.	20.010 – 20.018 (0.7878 – 0.7881)	20.040 (0.7890)
Conrod big end side clearance	0.170 – 0.320 (0.0067– 0.0126)	0.5 (0.02)
Conrod big end width	20.95 – 21.00 (0.825 – 0.827)	—
Crank pin width	42.17 – 42.22 (1.660 – 1.662)	—
Conrod big end oil clearance	0.032 – 0.056 (0.0013 – 0.0022)	0.080 (0.0031)
Crank pin O.D.	37.976 – 38.000 (1.4951 – 1.4960)	—
Crankshaft journal oil clearance	0.008 – 0.035 (0.0003 – 0.0014)	0.080 (0.0031)
Crankshaft journal O.D.	41.985 – 42.000 (1.6529 – 1.6535)	—
Crankshaft thrust bearing thickness	1.925 – 2.175 (0.0758 – 0.0856)	—
Crankshaft thrust clearance	0.050 – 0.110 (0.0020 – 0.0043)	—
Crankshaft runout	—	0.05 (0.002)

**OIL PUMP**

ITEM	STD/SPEC.	LIMIT
Oil pressure (at 60°C, 140°F)	Above 200 kPa (2.0 kgf/cm <sup>2</sup> , 28 psi) Below 600 kPa (6.0 kgf/cm <sup>2</sup> , 85 psi) at 3 000 r/min	—

**CLUTCH**

Unit: mm (in)

ITEM	STD/SPEC.	LIMIT
Clutch cable play	10 – 15 (0.4 – 0.6)	—
Clutch release screw	1/4 turn(s) back	—
Drive plate thickness	No.1	2.92 – 3.08 (0.115 – 0.121)
	No.2	3.42 – 3.58 (0.135 – 0.141)
Drive plate claw width	No.1 & No.2	15.9 – 16.0 (0.626 – 0.630)
Driven plate distortion	—	0.10 (0.004)
Clutch spring free length	58.9 (2.32)	56.0 (2.20)

**TRANSMISSION + DRIVE CHAIN**

Unit: mm (in)

ITEM	STD/SPEC.		LIMIT
Primary reduction ratio	2.088 (71/34)		—
Final reduction ratio	SV650S	2.933 (44/15)	—
	SV650	3.000 (45/15)	—
Gear ratios	Low	2.461 (32/13)	—
	2nd	1.777 (32/18)	—
	3rd	1.380 (29/21)	—
	4th	1.125 (27/24)	—
	5th	0.961 (25/26)	—
	Top	0.851 (23/27)	—
Shift fork to groove clearance	0.1 – 0.3 (0.004 – 0.012)		0.5 (0.020)
Shift fork groove width	5.5 – 5.6 (0.217 – 0.220)		—
Shift fork thickness	5.3 – 5.4 (0.209 – 0.213)		—
Drive chain	Type	DID525V8	
	Links	SV650	110 Links
		SV650S	108 Links
	20-pitch length	—	
Drive chain slack (on side-stand)	20 – 30 (0.79 – 1.18)		—
Gearshift lever height	SV650S	60 – 70 (2.4 – 2.8)	—
	SV650	55 – 60 (2.2 – 2.4)	—

**THERMOSTAT + RADIATOR + FAN + COOLANT**

ITEM	STD/SPEC.		LIMIT
Thermostat valve opening temperature	Approx. 82°C (179.6°F)		—
Thermostat valve lift	Over 8.0 mm (0.31 in) at 95°C (203°F)		—
Engine coolant temperature switch operating temperature	OFF → ON	Approx. 115°C (239°F)	—
	ON → OFF	Approx. 108°C (226.4°F)	—
Radiator cap valve opening pressure	95 – 125 kPa (0.95 – 1.25 kgf/cm <sup>2</sup> , 13.5 – 17.8 psi)		—
Cooling fan thermo-switch operating temperature	OFF → ON	Approx. 96°C (204.8°F)	—
	ON → OFF	Approx. 91 °C (195.8°F)	—
Engine coolant type	Use an anti-freeze/coolant compatible with aluminum radiator, mixed with distilled water only, at the ratio of 50:50.		—
Engine coolant including reserve	Reserve tank side	Approx. 250 ml (0.26/0.22 US/Imp qt)	—
	Engine side	Approx. 1 350 ml (1.43/1.19 US/Imp qt)	—

**CARBURETOR**

ITEM	STD/SPEC.	
	E-02, 04, 17, 22, 24, 25, 34	E-03, 28
Carburetor type	MIKUNI BDSR39	←
Bore size	39 mm	←
I.D. No.	20F0	20F2
Idle r/min	1 300 ± 100 r/min	←
Fuel level	16.9 ± 0.5 mm (0.68 ± 0.02 in)	←
Float height	7.0 ± 0.5 mm (0.28 ± 0.02 in)	←
Main jet (M.J.)	#137.5	#137.5
Jet needle (J.N.)	6E38-54-2	6E42-52
Needle jet (N.J.)	P-0	P-0M
Throttle valve (Th.V.)	#95	←
Pilot jet (P.J.)	#17.5	#15
Pilot screw (P.S.)	PRE-SET (2½ turns back)	PRE-SET (3 turns back)
Throttle cable play	2.0 – 4.0 mm (0.08 – 0.16 in)	←

**CARBURETOR**

ITEM	STD/SPEC.	
	E-33	E-22 (U-Type)
Carburetor type	MIKUNI BDSR39	←
Bore size	39 mm	←
I.D. No.	20F4	20F5
Idle r/min	1 300 ± 100 r/min	←
Fuel level	16.9 ± 0.5 mm (0.68 ± 0.02 in)	←
Float height	7.0 ± 0.5 mm (0.28 ± 0.02 in)	←
Main jet (M.J.)	#137.5	#137.5
Jet needle (J.N.)	6E43-54	6E38-54-2
Needle jet (N.J.)	P-0M	P-0
Throttle valve (Th.V.)	#95	←
Pilot jet (P.J.)	#15	#17.5
Pilot screw (P.S.)	PRE-SET	PRE-SET (3½ turns back)
Throttle cable play	2.0 – 4.0 mm (0.08 – 0.16 in)	←

**CARBURETOR**

ITEM	STD/SPEC.	
	E-18	
Carburetor type	MIKUNI BDSR39	
Bore size	39 mm	
I.D. No.	20F3	
Idle r/min	1 300 ± 50 r/min	
Fuel level	16.9 ± 0.5 mm (0.68 ± 0.02 in)	
Float height	7.0 ± 0.5 mm (0.28 ± 0.02 in)	
Main jet (M.J.)	#137.5	
Jet needle (J.N.)	6E38-54-2	
Needle jet (N.J.)	P-2	
Throttle valve (Th.V.)	#95	
Pilot jet (P.J.)	#15	
Pilot screw (P.S.)	PRE-SET (2¾ turns back)	
Throttle cable play	2.0 – 4.0 mm (0.08 – 0.16 in)	

**ELECTRICAL**

ITEM		STD/SPEC.		NOTE
Firing order		1 · 2		
Spark plug	Type	NGK: CR8E DENSO: U24ESR-N		
	Gap	0.7 – 0.8 mm (0.028 – 0.031 in)		
Spark performance		Over 8 mm (0.3 in) at 1 atm.		
Signal coil resistance		140 – 230 Ω		
Signal coil peak voltage		More than 3 V		
Ignition coil resistance	Primary	3.5 – 5.5 Ω		Terminal – Terminal
	Secondary	20 – 31 kΩ		Plug cap – Terminal
Ignition coil primary peak voltage		More than 150 V		
Generator coil resistance		0.2 – 0.55 Ω		
Generator Max. output		Approx. 300 W at 5 000 r/min		
Generator no-load voltage (When cold)		More than 70 V (AC) at 5 000 r/min		
Regulated voltage		13.5 – 15.0 V at 5 000 r/min		
Starter relay resistance		3 – 6 Ω		
Battery	Type designation	YT12A-BS		
	Capacity	12 V 36.0 kC (10Ah)/10HR		
Fuse size	Headlight	HI	15A	
		LO	15A	
	Signal	15A		
	Ignition	10A		
	Meter	10A		
	Main	30A		

**WATTAGE**

ITEM		STD/SPEC.			
		SV650S		SV650	
		E-02, 03, 24, 28, 33	The other countries	E-03, 24, 28, 33	The other countries
Headlight	HI	45 W × 2	55 W	60 W	←
	LO	45 W × 2	55 W	55 W	←
Parking or position light		5 W	←	←	5 W
Brake light/Taillight		21/5 W × 2	←	←	←
Turn signal light		21 W	←	←	←
License light		5 W	←	←	←
Speedometer light		0.84 W × 3	←	1.7 W × 2	←
Turn signal indicator light		3 W	←	1.7 W	←
High beam indicator light		1.7 W	←	←	←
Neutral indicator light		1.7 W	←	←	←
Oil pressure indicator light		1.7 W	←	←	←

**BRAKE + WHEEL**

Unit: mm (in)

ITEM	STD/SPEC.		LIMIT
Rear brake pedal free travel	20 – 30 (0.8 – 1.2)		—
Rear brake pedal height	55 – 65 (2.17 – 2.56)		—
Brake disc thickness	Front	4.5 (0.18)	4.0 (0.16)
	Rear	5.0 (0.20)	4.5 (0.18)
Brake disc runout	—		0.3 (0.012)
Master cylinder bore	Front	15.870 – 15.913 (0.6248 – 0.6265)	—
	Rear	12.700 – 12.743 (0.5000 – 0.5017)	—
Master cylinder piston diam.	Front	15.827 – 15.854 (0.6231 – 0.6242)	—
	Rear	12.657 – 12.684 (0.4983 – 0.4994)	—
Brake caliper cylinder bore	Front	30.230 – 30.306 (1.1902 – 1.1931)	—
	Rear	38.180 – 38.256 (1.5031 – 1.5061)	—
Brake caliper piston diam.	Front	30.150 – 30.200 (1.1870 – 1.1890)	—
	Rear	38.098 – 38.148 (1.4999 – 1.5019)	—
Brake fluid type	DOT 4		
Wheel rim runout	Axial	—	2.0 (0.08)
	Radial	—	2.0 (0.08)
Wheel rim size	Front	17 × MT3.50	—
	Rear	17 × MT4.50	—
Wheel axle runout	Front	—	0.25 (0.010)
	Rear	—	0.25 (0.010)

**TIRE**

Unit: mm (in)

ITEM	STD/SPEC.		LIMIT
Cold inflation tire pressure (Solo riding)	Front	225 kPa (2.25 kgf/cm <sup>2</sup> , 33 psi)	—
	Rear	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)	—
Cold inflation tire pressure (Dual riding)	Front	225 kPa (2.25 kgf/cm <sup>2</sup> , 33 psi)	—
	Rear	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)	—
Tire size	Front	120/60ZR17 (55W)	—
	Rear	160/60ZR17 (69W)	—
Tire type	Front	METZELER: MEZ4 FRONT	—
	Rear	METZELER: MEZ4	—
Tire tread depth [Recommend depth]	Front	—	0.8 (0.03) [1.6 (0.06)]
	Rear	—	0.8 (0.03) [2.0 (0.08)]

**SUSPENSION**

Unit: mm (in)

ITEM	STD/SPEC.		LIMIT
Front fork stroke	130 (5.1)		—
Front fork spring free length	314.6 (12.39)		308 (12.13)
Front fork oil level (without spring, inner tube fully compressed)	E-03, 33	102 (4.02)	—
	Others	104 (4.09)	—
Front fork oil type	SUZUKI FORK OIL G10 (#10) or equivalent fork oil		—
Front fork oil capacity (each leg)	E-03, 33	491 ml (16.6/17.3 US/Imp oz)	—
	Others	489 ml (16.5/17.2 US/Imp oz)	—
Rear shock absorber spring adjuster	SV650S	4/7	—
	SV650	2/7	—
Rear wheel travel	125 (4.9)		—
Swingarm pivot shaft runout	—		0.3 (0.01)

**FUEL + OIL**

ITEM	STD/SPEC.		NOTE
Fuel type	Use only unleaded gasoline of at least 87 pump octane ( $\frac{R+M}{2}$ ) or 91 octane or higher rated by the research method. Gasoline containing MTBE (Methyl Tertiary Butyl Ether), less than 10% ethanol, or less than 5% methanol with appropriate cosolvents and corrosion inhibitor is permissible.		E-03, 33
	Use only unleaded gasoline of at least 87 pump octane ( $\frac{R+M}{2}$ ) or 91 octane or higher rated by the research method.		E-28
	Gasoline used should be graded 91 octane or higher. An unleaded gasoline is recommended.		The others
Fuel tank capacity	15 L (4.0/3.3 US/Imp gal)		E-33
	16 L (4.2/3.5 US/Imp gal)		The others
Engine oil type	SAE 10W/40, API SF or SG		
Engine oil capacity	Change	2 300 ml (2.4/2.0 US/Imp qt)	
	Filter change	2 400 ml (2.5/2.1 US/Imp qt)	
	Overhaul	3 000 ml (3.2/2.6 US/Imp qt)	