

Air Cleaner	3-6	Flywheel Removal	9-3
Case	4-4	Fork	12-10
Alternator/Starter Clutch	9-1	Front Wheel/Suspension/Steering	12-1
Alternator	16-7	Wheel	12-5
Balancer/Crankshaft Removal	10-4	Fuel System	4-1
Battery/Charging System	16-1	Line/Fuel Strainer	3-4
Battery	16-3	Tank	4-3
Brake Caliper	14-9	Gearshift Cam	8-9
Brake Fluid	3-10	General Information	1-1
Replacement/Air Bleeding	14-3	Safety	1-1
Brake Light Switch	19-8	Handlebar	12-3
Pad/Disc	14-4	Headlight	19-2
Shoe/Pad Wear	3-10	Aim	3-12
System	3-11	High Altitude Adjustment (U.S.A. only)	4-17
Brakelight Switch	3-11	Horn	19-9
Cable & Harness Routing	1-9	Hydraulic Brake	14-1
Cam Chain Tensioner Removal	6-9	Ignition System	17-1
Camshaft Installation	6-17	Coil	17-5
Removal	6-5	Switch	19-6
Carburetor	4-7	Timing	17-7
Choke	3-5	Instruments	19-4
Idle Speed	3-8	Left Crankcase Cover Assembly	9-7
Charging System	16-5	Disassembly	9-3
Clutch	8-1, 8-2	Installation	9-7
Diode	18-8	Removal	9-2
Switch	19-8	Left Handlebar Switch	19-7
System	3-12	License Light	19-3
Crankcase Assembly	10-11	Lights/Instruments/Switches	19-1
Bearing Replacement	10-6	Lubrication	2-1
Breather	4-6	Points	2-14
Separation	10-3	Maintenance	3-1
Crankshaft/Balancer	10-1	Schedule	3-3
Installation	10-10	Master Cylinder	14-6
Cylinder Head/Valves	6-1	Model Identification	1-2
Cylinder/Piston	7-1	Neutral Switch	19-9
Cylinder Compression	3-7	Nuts, Bolts, Fasteners	3-15
Head Assembly	6-15	Oil Pipe Inspection	2-4
Cylinder Head Cover Assembly	6-18	Pump	2-5
Disassembly	6-4	Strainer Nut	2-5
Installation	6-19	Strainer Screen Cleaning	2-4
Removal	6-3	Pilot Screw Adjustment (Idle Drop Procedure)	4-16
Cylinder Head Disassembly	6-10	Piston Installation	7-5
Installation	6-16	Removal	7-3
Removal	6-9	Primary Drive Gear	8-7
Cylinder Installation	7-6	Pulse Generator	17-7
Removal	7-2	Purge Control Valve Inspection (California model)	4-17
Drive Chain	3-8	Rear Wheel/Brake/Suspension	13-1
Slider	3-10	Brake	13-9
Electric Starter System	18-1	Fender	15-5
Emission Control Information/labels (U.S.A. only)	1-18	Wheel	13-3
Systems	1-16	Regulator/Rectifier	16-6
Engine Removal/Installation	5-1	Right Crankcase Cover Installation	8-9
Installation	5-3	Removal	8-2
Engine Oil Change	2-3	Right Handlebar Switch	19-8
Filter Replacement	2-4	Secondary Air Supply System (California model)	4-19
Level Check	2-3	Service Information	
Engine Removal	5-2	Alternator/Starter Clutch	9-1
Exhaust Pipe/Muffler	15-7	Battery/Charging System	16-1
Fairing/Exhaust System	15-1	Clutch	8-1
Fairing	15-2	Crankshaft/Balancer	10-1
Flywheel Installation	9-6		

INDEX

Cylinder Head/Valves	6-1
Cylinder/Piston	7-1
Electric Starter System	18-1
Engine Removal/Installation	5-1
Fairing/Exhaust System	15-1
Front Wheel/Suspension/Steering	12-1
Fuel System	4-1
Hydraulic Brake	14-1
Ignition System	17-1
Lights/Instruments/Switches	19-1
Lubrication	2-2
Maintenance	3-1
Rear Wheel/Brake/Suspension	13-1
Transmission	11-1
Service Rules	1-1
Shock Absorber	13-12
Linkage	13-15
Side Cover/Seat	15-2
Stand	3-13
Spark Arrester (U.S.A. only)	3-13
Plug	3-6
Specifications	1-3
Starter Clutch	9-4
Motor	18-3
Relay Switch	18-7
Steering Head Bearing	3-15
Stem	12-17
Stop/Taillight	19-3
Suspension	3-14
Swing Arm	13-18
System Diagram	16-0, 17-0, 18-0
Inspection	17-3
Throttle Operation	3-4
Tools	1-7
Torque Values	1-5
Transmission	11-1
Assembly	11-6
Disassembly	11-3
Troubleshooting	
Alternator/Starter Clutch	9-1
Battery/Charging System	16-2
Clutch	8-1
Crankshaft/Balancer	10-2
Cylinder Head/Valves	6-2
Cylinder/Piston	7-1
Electric Starter System	18-2
Front Wheel/Suspension/Steering	12-2
Fuel System	4-2
Hydraulic Brake	14-2
Ignition System	17-2
Lights/Instruments/Switches	19-1
Lubrication	2-2
Rear Wheel/Brake/Suspension	13-2
Transmission	11-2
Turn Signal Light	19-4
Valve Clearance	3-6
Seat Inspection Andrefacing	6-12
Wheels/Tires	3-15
Wiring Diagram	20-1