

AIR CLEANER	3-6	EVAPORATIVE EMISSION CONTROL SYSTEM (California type only)	3-19
AIR CLEANER HOUSING	5-64	FAN CONTROL RELAY	6-17
ALTERNATOR CHARGING COIL	16-7	FAST IDLE WAX UNIT	5-75
ALTERNATOR COVER INSTALLATION	10-8	FLYWHEEL INSTALLATION	10-7
ALTERNATOR COVER REMOVAL	10-2	FLYWHEEL REMOVAL	10-3
BANK ANGLE SENSOR	5-85	FORK	13-15
BATTERY	16-4	FRONT BRAKE CALIPER	15-21
BODY PANEL LOCATIONS	2-0	FRONT FENDER	2-8
BRAKE FLUID	3-24	FRONT MASTER CYLINDER	15-12
BRAKE FLUID REPLACEMENT/AIR BLEEDING	15-4	FRONT WHEEL	13-9
BRAKE LIGHT SWITCH	3-26	FUEL CUT-OFF RELAY	5-58
BRAKE LIGHT SWITCH	19-18	FUEL LINE	3-4
BRAKE PAD WEAR	3-25	FUEL LINE INSPECTION	5-54
BRAKE PAD/DISC	15-8	FUEL PUMP	5-57
BRAKE PEDAL	15-28	FUEL RESERVE SENSOR	19-15
BRAKE SYSTEM	3-25	FUEL TANK	5-59
BRAKE/TAIL LIGHT	19-6	GEARSHIFT LINKAGE	9-12
CABLE & HARNESS ROUTING	1-23	HANDLEBAR SWITCHES	19-17
CAMSHAFT INSTALLATION	8-24	HANDLEBARS	13-4
CAMSHAFT REMOVAL	8-7	HEADLIGHT	19-4
CAM PULSE GENERATOR	5-83	HEADLIGHT AIM	3-27
CAM CHAIN TENSIONER LIFTER	8-32	HORN	19-20
CHARGING SYSTEM INSPECTION	16-6	IAT SENSOR	5-82
CLUTCH	9-4	IGNITION PULSE GENERATOR	17-6
CLUTCH SYSTEM	3-27	IGNITION SYSTEM INSPECTION	17-4
CLUTCH SWITCH	19-19	IGNITION SWITCH	19-16
COOLANT REPLACEMENT	6-4	IGNITION TIMING	17-8
COOLING SYSTEM	3-18	INJECTORS	5-72
COMBINATION METER	19-8	INNER MIDDLE COWL	2-7
CRANKCASE COMBINATION	11-12	LICENSE LIGHT	19-7
CRANKCASE SEPARATION	11-3	LOWER BRACKET INSTALLATION	7-12
CRANKSHAFT	12-3	LOWER BRACKET REMOVAL	7-2
CYLINDER COMPRESSION TEST	8-4	LOWER COWL	2-7
CYLINDER HEAD ASSEMBLY	8-20	LUBRICATION SYSTEM DIAGRAM	4-0
CYLINDER HEAD COVER ASSEMBLY	8-29	LUBRICATION & SEAL POINTS	1-19
CYLINDER HEAD COVER DISASSEMBLY	8-6	MAINTENANCE SCHEDULE	3-3
CYLINDER HEAD COVER INSTALLATION	8-30	MAP SENSOR	5-81
CYLINDER HEAD COVER REMOVAL	8-5	MODEL IDENTIFICATION	1-1
CYLINDER HEAD DISASSEMBLY	8-13	MUFFLER/EXHAUST PIPE	2-13
CYLINDER HEAD INSPECTION	8-14	NEUTRAL SWITCH	19-18
CYLINDER HEAD INSTALLATION	8-22	NUTS, BOLTS, FASTENERS	3-31
CYLINDER HEAD REMOVAL	8-12	O ₂ SENSOR (California type only)	5-90
DIODE	18-11	OIL COOLER	4-9
DRIVE CHAIN	3-20	OIL PRESSURE SWITCH	19-14
DUCT COVER	2-4	OIL PRESSURE INSPECTION	4-3
ECT SENSOR	5-82	OIL PUMP	4-5
ECT/THERMO SENSOR	13-12	OIL STRAINER/PRESSURE RELIEF VALVE	4-3
ECM (ENGINE CONTROL MODULE)	5-87	PAIR SOLENOID VALVE	5-88
EGCV	5-97	PGM-FI (PROGRAMMED FUEL INJECTION) SYSTEM	5-6
EGCV AND AIR INTAKE VALVE INSPECTION	5-92	PGM-FI SELF-DIAGNOSIS MALFUNCTION INDICATOR LAMP (MIL) FAILURE CODES	5-10
EGCV AND AIR INTAKE VALVE SERVO MOTOR	5-95	PILLION SEAT/REAR COWL	2-2
EMISSION CONTROL INFORMATION LABELS	1-40	PISTON/CONNECTING ROD	11-4
EMISSION CONTROL SYSTEMS	1-37	PRESSURE REGULATOR	5-74
ENGINE IDLE SPEED	3-17	RADIATOR	6-8
ENGINE INSTALLATION	7-7	RADIATOR COOLANT	3-18
ENGINE OIL/OIL FILTER	3-15	RADIATOR RESERVE TANK	6-16
ENGINE REMOVAL	7-3	REAR BRAKE CALIPER	15-25
ENGINE STOP RELAY	5-86	REAR FENDER	2-9
EVAP PURGE CONTROL SOLENOID VALVE (California type only)	5-89		

REAR MASTER CYLINDER	15-17	TP SENSOR	5-84
REAR WHEEL	14-3	TRANSMISSION	12-9
REGULATOR/RECTIFIER	16-7	TROUBLESHOOTING	
RIGHT CRANKCASE COVER INSTALLATION	9-17	(ALTERNATOR/STARTER/CLUTCH)	10-1
RIGHT CRANKCASE COVER REMOVAL	9-3	(BATTERY/CHARGING SYSTEM)	16-3
SEAT	2-2	(CLUTCH/GEARSHIFT LINKAGE)	9-2
SEAT RAIL	2-11	(COOLING SYSTEM)	6-2
SERVICE RULES	1-1	(CRANKCASE/PISTON/CYLINDER)	11-2
SECONDARY AIR SUPPLY SYSTEM	3-19	(CRANKSHAFT/TRANSMISSION)	12-2
SERVICE INFORMATION		(CYLINDER HEAD/VALVES)	8-3
(ALTERNATOR/STARTER CLUTCH)	10-1	(ELECTRIC STARTER)	18-2
(BATTERY/CHARGING SYSTEM)	16-1	(ENGINE DOES NOT START OR IS HARD TO START)	21-1
(CLUTCH/GEARSHIFT LINKAGE)	9-1	(ENGINE LACKS POWER)	21-2
(COOLING SYSTEM)	6-1	(FRAME/BODY PANELS/EXHAUST SYSTEM)	2-1
(CRANKCASE/PISTON/CYLINDER)	11-1	(FRONT WHEEL/SUSPENSION/STEERING)	13-3
(CRANKSHAFT/TRANSMISSION)	12-1	(FUEL SYSTEM)	5-3
(CYLINDER HEAD/VALVES)	8-1	(HYDRAULIC BRAKE)	15-3
(ELECTRIC STARTER)	18-1	(IGNITION SYSTEM)	17-3
(ENGINE REMOVAL/INSTALLATION)	7-1	(LIGHTS/METERS/SWITCHES)	19-3
(FRAME/BODY PANELS/EXHAUST SYSTEM)	2-1	(LUBRICATION SYSTEM)	4-2
(FRONT WHEEL/SUSPENSION/STEERING)	13-1	(POOR HANDLING)	21-4
(FUEL SYSTEM)	5-1	(POOR PERFORMANCE AT HIGH SPEED)	21-4
(HYDRAULIC BRAKE)	15-2	(POOR PERFORMANCE AT LOW AND IDLE SPEED)	21-3
(IGNITION SYSTEM)	17-1	(REAR WHEEL/SUSPENSION)	14-2
(LIGHTS/METERS/SWITCHES)	19-1	TURN SIGNAL	19-6
(LUBRICATION SYSTEM)	4-1	TURN SIGNAL RELAY	19-21
(MAINTENANCE)	3-1	UPPER COWL	2-5
(REAR WHEEL/SUSPENSION)	14-1	VALVE CLEARANCE	3-10
SHOCK ABSORBER	14-11	VALVE GUIDE REPLACEMENT	8-17
SIDE STAND	3-28	VALVE SEAT INSPECTION/REFACING	8-18
SIDE STAND SWITCH	19-19	VARIABLE AIR INTAKE VALVE	5-104
SPARK PLUGS	3-6	WATER PUMP	6-13
SPECIFICATIONS	1-3	WHEELS/TIRES	3-31
SPEEDOMETER/VEHICLE SPEED SENSOR	19-9	WINDSCREEN	2-8
STARTER CLUTCH	10-5	WIRING DIAGRAMS	20-1
STARTER MOTOR	18-4		
STARTER RELAY SWITCH	18-10		
STARTER VALVE	5-76		
STARTER VALVE SYNCHRONIZATION	5-79		
STATOR	10-2		
STEERING HEAD BEARINGS	3-32		
STEERING STEM	13-26		
SUSPENSION	3-28		
SUSPENSION LINKAGE	14-9		
SWINGARM	14-14		
SYSTEM DIAGRAM			
(BATTERY/CHARGING SYSTEM)	16-0		
(ELECTRIC STARTER)	18-0		
(FUEL SYSTEM)	5-5		
(IGNITION SYSTEM)	17-0		
SYSTEM LOCATION			
(FUEL SYSTEM)	5-4		
(LIGHTS/METERS/SWITCHES)	19-0		
SYSTEM FLOW PATTERN	6-0		
SYSTEM TESTING	6-3		
TACHOMETER	19-12		
THERMOSTAT	6-6		
THROTTLE BODY	5-67		
THROTTLE OPERATION	3-5		
TORQUE VALUES	1-12		
TOOLS	1-17		