



IGNITION SWITCH

	FAN	IG	BATI
ON	○	○	○
OFF			
LOCK			
COLOR	Bu/O	R/BI	R

TURN SIGNAL SWITCH

	W	R	L	BATS	PR	PL
R	○					
N				○	○	○
L			○			
COLOR	Gr	Lb	O	B/B	Lb/W	O/W

DIMMER SWITCH

	HL	Lo	Hi
Lo			
(N)			
Hi	○		
COLOR	W		Bu

HORN SWITCH

	HO	BATS
FREE		
PUSH	○	
COLOR	Lg	B/B