

Subject / Vehicles:

Oil Change Proceedure for Bajaj Legend and Chetak

1. Open oil drain plug at bottom of engine and drain oil.
2. Remove oil filter and clean screen.
3. Install drain plug and filter screen.
4. Add 1 quart API SJ grade oil or better (summer 15W 50, winter 5W 30) through valve adjust cover. Synthetic oils are not recommended as some will cause clutch slippage.
5. Check oil level with the dipstick:
  - A. Unscrew dipstick, remove and wipe dry with a clean rag.
  - B. Insert dipstick back in hole, but do not screw in.
  - C. Remove dipstick and check that oil covers up to between the lines on the stick.
  - D. Replace dipstick and screw firmly back in place.

**CAUTION:** *Be careful not to cross threads when replacing caps.* To avoid damaging the aluminum threads, be sure caps can be turned with fingers several turns until they are completely seated. A wrench may then be used to snug oil screen and oil fill caps.

6. Wipe any oil off the engine and check that all fittings are tight and not leaking.

